



Operation and maintenance manual Seed drill

Cerex 300 and Cerex 400 Comfort
Translation of the original manual
EN

www.multiva.info

Table of contents

1. Foreword	7
1.1. Purpose of the machine	7
1.2. Specifications	7
1.3. Type plate	10
1.4. Liability terms and conditions	10
1.5. Tightening torques	11
2. Warranty terms	12
3. Safety instructions	13
3.1. Residual risks	13
3.2. Symbols used in the operating manual	15
3.3. Warning labels used on the machine	17
3.4. Using the middle marker ball valves	23
4. Control systems	24
4.1. Lykketronic area counter	24
4.1.1. Counter components	24
4.1.2. Counter buttons and display	25
4.1.3. Using the counter	26
4.1.3.1. Setting the machine's working width	26
4.1.3.2. Setting the value of advance	26
4.1.3.3. Resetting the area counter	27
4.1.3.4. Switching power on and off	27
4.2. Comfort control system	28
4.2.1. Control system components	28
4.2.1.1. Speed sensor	28
4.2.1.2. Seeding position sensor	28
4.2.1.3. Hopper level sensors	29
4.2.1.4. Tramline clutches	30
4.2.1.5. Tramline clutch extensions	31
4.2.1.6. Linear actuator for remote control	31
4.2.2. Comfort controller buttons	32
4.2.3. User interface	33
4.2.4. Using the user interface	35
4.2.4.1. User setup	35
5. Commissioning and basic settings	41
5.1. Rendering to operating condition	41
5.1.1. Mounting the wheel packer	41
5.1.2. Mounting the drawbar cylinder	44
5.1.3. Attaching the turnbuckle	45
5.1.4. Mounting the front levelling board	45
5.1.5. Mounting the middle markers	48
5.1.6. Removing the transport supports	48
5.1.7. Mounting the scraper	49
5.1.8. Mounting the rear harrow	50
5.1.9. Mounting the rear markers on the rear harrow	52
5.1.10. Turning the rear railing of the working platform and attaching the end railing	55
5.2. Commissioning	56
5.2.1. Installing the Lykketronic area counter	56

5.2.2. Installing the Comfort control panel	57
5.3. Connecting to tractor	58
5.3.1. Adjusting the length of the boom of the wheel packer	61
5.3.2. Using the ground support	62
5.3.3. Adjusting the lengthwise level of the machine with a turnbuckle ...	62
5.3.4. Adjusting the lengthwise level of the machine with a drawbar cylinder	63
5.3.5. Using the machine lifting circuit ball valve	64
5.3.6. Ensuring the steerability of the tractor	65
5.3.7. Adjusting the middle markers	65
6. Machine adjustment and use	66
6.1. Rendering the machine to the transport position	66
6.2. Rendering the machine to the working position	67
6.3. Comfort control system operating settings	68
6.3.1. Active operating mode	68
6.3.2. Using the middle markers	70
6.3.3. Using the tramline counter	71
6.3.4. Setting the fertiliser target rate	72
6.3.5. Selecting the setting method for adjusting of fertiliser target rate ...	73
6.3.6. Area counter use	73
6.4. Feed units	74
6.5. Seeding quantities	74
6.6. Preparations preceding hopper filling	78
6.6.1. Preparations preceding hopper filling in a machine without a gearbox	78
6.6.2. Preparations preceding hopper filling in a machine with a gearbox on the seed side or a dual gearbox	79
6.6.3. Preparations preceding hopper filling in a machine with a small seed hopper	79
6.6.4. Adjusting the hopper divider	80
6.6.5. Adjusting the width of the feeder roller	82
6.6.6. Adjusting the feeding quantity with chain gears	83
6.6.7. Adjusting the feeding quantity with the gearbox control lever	84
6.6.8. Adjusting the bottom flap position	84
6.6.9. Adjusting the shut-off plate position	85
6.6.10. Adjusting the width of the small seed feeder roller	86
6.6.11. Adjusting the bottom flap position in the feeder units of the small seed hopper	87
6.6.12. Adjusting the shut-off plate position in the feeder units of the small seed hopper	88
6.7. Filling the hoppers	88
6.8. Product calibration	90
6.8.1. Fertiliser calibration test in a machine without a gearbox or with a gearbox on the seed side	90
6.8.2. Fertiliser calibration test in a machine with a dual gearbox	92
6.8.3. Calibration test with adjusting of fertiliser target rate - basic model .	93
6.8.4. Calibration test with adjusting of fertiliser target rate - machine with dual gearbox	97
6.8.5. Seed calibration test in a machine without a gearbox	101
6.8.6. Seed calibration test in a machine with a gearbox on the seed side or a dual gearbox	102

6.8.7. Calibration test of the small seed hopper	104
6.9. Adjusting the seeding depth of the coulter	106
6.10. Adjusting the coulter pressure	107
6.11. Adjusting the rear harrow	108
6.12. Adjusting the front levelling board	109
6.13. Controlling the seeding depth	109
6.14. Securing the position of the middle markers	109
6.15. Emptying the hoppers	110
6.15.1. Emptying the hoppers to the calibration tray	110
6.15.2. Emptying the hoppers through the coulters	110
6.16. Emptying the small seed hopper	111
6.16.1. Emptying the small seed hopper to the calibration tray	111
6.16.2. Emptying the small seed hopper through pipes	111
6.17. Disconnecting from the tractor	112
6.18. Machine storage	112
7. Maintenance	114
7.1. Inspections	115
7.1.1. Quick instructions, inspections	115
7.1.2. Checking bolt tightness	116
7.1.2.1. Checking the tightness of the wheel bolts of the transport wheels	116
7.1.2.2. Checking the tightness of the bolts in the flange bearings of the transport wheels	117
7.1.2.3. Checking the tightness of the wheel bolts of the wheel packer	118
7.1.2.4. Checking the tightness of coulter bolts	119
7.1.2.5. Checking the tightness of the working platform bolts ..	121
7.1.2.6. Checking the tightness of the towing eye bolts	122
7.1.3. Checking tyre pressure	122
7.1.4. Checking the bearing clearance of the wheel packer hubs	122
7.1.5. Checking the tightness of the transmission chains	123
7.1.5.1. Inspecting the tightness of the chains in a machine without a gearbox	123
7.1.5.2. Checking the tightness of chains in a machine with a gearbox on the seed side	123
7.1.5.3. Checking the tightness of chains in a machine with a dual gearbox	124
7.1.5.4. Checking the tightness of the chains in the small seed hopper transmission	124
7.1.6. Checking the tightness of the wheel drive chain	125
7.1.7. Inspecting the wheel drive clutch	126
7.1.8. Inspecting the wheel drive clearance	127
7.1.9. Checking the condition of hydraulics	127
7.1.10. Checking the condition of electric wires	127
7.1.11. Inspecting the towing eye	127
7.1.12. Checking the gearbox oil level	128
7.1.13. Inspecting the coulter discs	129
7.1.14. Checking the functioning of the adjusting of fertiliser target rate .	130
7.2. Lubrication	130
7.2.1. Quick instructions, lubrication	131
7.2.2. Lubricating the transmission chains	132

7.2.2.1. Lubricating the chains in a machine without a gearbox	132
7.2.2.2. Lubricating the chains in a machine with a gearbox on the seed side	132
7.2.2.3. Lubricating the chains in a machine with a dual gearbox	133
7.2.2.4. Lubricating the small seed hopper transmission chains	133
7.2.3. Lubricating the wheel drive	134
7.2.3.1. Lubricating the wheel drive chain	134
7.2.3.2. Lubricating wheel axle bearings	134
7.2.4. Lubricating the coulter pressure cylinder	135
7.2.5. Lubricating the rear axle mounting	136
7.2.6. Lubricating the wheel axle bearings	136
7.2.7. Lubricating the lifting cylinder	137
7.2.8. Lubricating the towing eye	137
7.2.9. Lubricating the middle marker cylinders	138
7.2.10. Lubricating the rear marker cylinders	138
7.2.11. Lubricating the wheel packer pins and wheel hubs.	139
7.2.12. Lubricating the front levelling board cylinders	140
7.2.13. Lubricating the drawbar cylinder	141
7.2.14. Lubricating the turnbuckle	141
7.3. Cleaning	142
7.3.1. Cleaning the hoppers	142
7.3.2. Cleaning the small seed hopper	143
7.3.3. Cleaning the paint surface	144
7.3.4. Cleaning the coulter discs	144
7.3.5. Cleaning the feeder units	145
7.3.6. Cleaning the small seed hopper feeder units	145
7.4. Transport wheel assembly wheel set	146
7.4.1. Demounting the wheel set	146
7.4.2. Disassembling a wheel set	150
7.4.3. Mounting a wheel set	151
7.4.4. Mounting the wheel set	152
7.5. Tightening the transmission chains	153
7.5.1. Tightening the chains in a machine without a gearbox	153
7.5.2. Tightening the chains in a machine with a gearbox on the seed side	153
7.5.3. Tightening the chains in a machine with a dual gearbox	154
7.5.4. Tightening the transmission chains of the small seed hopper	155
7.6. Wheel hub bearing clearance of the wheel packer	156
7.6.1. Tightening the bearing	156
7.7. Wheel drive	157
7.7.1. Tightening the wheel drive chain	157
7.7.2. Replacing the wheel drive clutch	158
7.7.2.1. Demounting the clutch	158
7.7.2.2. Installing the clutch	158
7.8. Towing eye	159
7.8.1. Replacing the towing eye	159
7.8.1.1. Detaching the towing eye	159
7.8.1.2. Installing the towing eye	159
7.9. Coulters	160
7.9.1. Replacing a coulter	160

7.9.1.1. Demounting a coulter	160
7.9.1.2. Installing a coulter	161
7.9.2. Replacing a coulter disc	163
7.9.2.1. Detaching a disc	163
7.9.2.2. Installing a disc	164
7.9.3. Replacing a coulter bearing	165
7.9.3.1. Detaching a bearing	165
7.9.3.2. Installing a bearing	166
7.9.4. Replacing the coulter covering wheel	167
7.9.4.1. Demounting the covering wheel	167
7.9.4.2. Installing the covering wheel	168
7.9.5. Adjusting the scrapers	168
7.9.5.1. Adjusting the disc scraper	168
7.9.5.2. Adjusting the cover wheel scraper	169
7.10. Comfort control system maintenance	170
7.10.1. Manual calibration of the speed sensor	170
7.10.2. Calibration of the speed sensor while driving	170
8. Fault situations	172
8.1. Troubleshooting the Comfort control system	172
8.2. Troubleshooting of the seed drill	175
9. Attachments	177
9.1. EC declaration of conformity	178
9.2. Hydraulic schematics	179
9.3. Electrical schematics	183
9.4. Connection socket according to SFS 2473	186
9.5. Calculating the stability of the tractor - seed drill combination	187

1. Foreword

Thank you for choosing a high-class Multiva Cerex seed drill. We hope the product will meet your requirements and provide years of reliable service. Please read this manual thoroughly before operating the machine. It is important that you perform the inspection and maintenance measures specified in this manual to ensure the flawless operation of the machine and the validity of the warranty. You must follow all the instructions, warnings and prohibitions related to the use of the machine. They are provided to ensure operator safety and the long service life of the machine.

Cerex is an effective and versatile seed drill for seeding tilled soil. The machine is equipped with a separate wheel for working depth adjustment, which provides precision seeding in ploughed, reduced tillage and no tillage soils.

These instructions cover the Cerex 300 and Cerex 400 seed drills and the Lykketronic and Comfort control systems.

1.1. Purpose of the machine

The operator of the seed drill must acquaint themselves with the machine and read and understand the contents of its operating manual before operating the machine. The seed drill may only be operated when it is in a flawless technical condition. The seed drill must be used in accordance with regulations, identifying hazards and following the safety and operating instructions.

Original Multiva spare parts and accessories are designed for this particular seed drill. The manufacturer bears no responsibility for spare parts and accessories provided by other suppliers. Using them in certain circumstances may weaken the machine and compromise personal safety.

The machine is intended for sowing seeds and applying fertiliser. The construction of the machine allows road transport with the hoppers full. Any use exceeding this, such as using the machine for transport, is not considered to be in accordance with the regulations. Use in accordance with the regulations includes following the operating instructions and manufacturer's instructions as well as regulations concerning service and maintenance. Occupational safety regulations concerning agricultural machinery, other rules and regulations on general safety technology and occupational health as well as traffic rules and regulations must be followed.

1.2. Specifications

Table. 1.2. - 1. Specifications

Specifications	Cerex 300	Cerex 400
Working width (cm)	300	400
Transportation height (cm)	340 with middle markers 260 without middle markers	

Transportation width (cm)	300	409
Hopper filling height (cm)	210	
Weight (kg)	3,300	4,350
Hopper volume (L)	3,500	4,800
Coulter pressure (kg)	20-80	
Tyres	250/80-18	
Coulters (pcs)	20	26
Furrow spacing (mm)	150	154
Recommended working speed (km/h)	8-12	
Normal track width of tramline (mm)	1,650	1,694
Alternative track width of tramline (mm)	1,950	2,002
Extended track width of tramline (mm)	1,800	1,848
Tractor power requirement (hp)	90	120

Table. 1.2. - 2. Standard equipment

Standard equipment on the Cerex 300 and Cerex 400
Back and front railings
Working platform stairs on the left
Sieves for fertiliser hopper
Wheel drive from transport wheels
Adjustable hopper dividers
Covering wheel scrapers
Coulter pressure adjustment indicator
Controller type (select one of the following): <ul style="list-style-type: none"> • LykkeTronic area counter • Comfort controller • SeedPilot controller - with a 7" display • SeedPilot ISOBUS controller <ul style="list-style-type: none"> ◦ No display included
Towing method (select one of the following) <ul style="list-style-type: none"> • Hitch (drawbar with a Scharmuller towing eye) • Hitch with drawbar cylinder • Wheel packer with a drawbar cylinder

Transmission (select one of the following)

- Chain gear (no gearbox)
- Gearbox on the seed side
- Gearbox on the fertiliser and seed side (dual gearbox)

Table. 1.2. - 3. Accessories for the Cerex 300 and Cerex 400

Accessories for the Cerex 300 and Cerex 400
Dual hopper level sensors <ul style="list-style-type: none"> • Available with the Comfort, SeedPilot or SeedPilot ISOBUS control systems
Adjusting of fertiliser target rate - basic model <ul style="list-style-type: none"> • Available with the Comfort, SeedPilot or SeedPilot ISOBUS control systems • Available with machines equipped with a chain gear or gearbox on the seed side
Adjusting of fertiliser target rate - machine with dual gearbox <ul style="list-style-type: none"> • Available with the Comfort, SeedPilot or SeedPilot ISOBUS control systems • Available with machines equipped with a chain gear or gearbox on the fertiliser and seed side
Dispersing axle
Front platform
Front levelling board <ul style="list-style-type: none"> • Available with the wheel packer
Middle markers <ul style="list-style-type: none"> • Available with the Comfort, SeedPilot or SeedPilot ISOBUS control systems
Transport set - 2.45 m
Rear harrow
Rear markers for the rear harrow
Feeder cover - front
Feeder cover - rear
Small seed hopper
Scraper for the rear wheels
Tramline extensions <ul style="list-style-type: none"> • Available with the Comfort, SeedPilot or SeedPilot ISOBUS control systems

1.3. Type plate

The type plate is located under the transmission cover in the left end.




Figure. 1.3. - 1. Location and details of the type plate

Table. 1.3. - 4. Details of the type plate

1.	CE marking
2.	Machine manufacturer
3.	Machine serial number
4.	Machine model
5.	Manufacturing year
6.	Manufacturer's information

1.4. Liability terms and conditions

The Cerex seed drills have been quality inspected and their operation has been tested before delivery. However, the owner/operator is responsible for the operation of the machine in practical circumstances. Damage compensation claims not concerning the machine itself as well as those concerning damages caused by misuse or incorrect adjustments of the machine will be rejected.

The machine manufacturer is not liable for any use of the machine that is in violation of laws, safety regulations or this operating manual.

Note that inappropriate use of fertilisers and plant protecting agents may cause damage to plants, humans, animals, water system or soil. Follow the instructions provided by the manufacturers of these substances and other experts as well as the authorities in handling and using said substances.

The manufacturer is not responsible for the selection of an incorrect quantity of seeds, plant protecting agents or fertiliser or incorrect seeding depth. The operator must constantly make sure that the desired seeding depth is maintained. If you lack information or knowledge gained through experience, please consult an expert for advice. The manufacturer is not responsible for any failures in seeding. The operator must continuously monitor the consumption of seeds and fertiliser in order to make sure that sowing quantities stay at a proper level in all seeding coulters.

The manufacturer is not liable for damages caused by the use of components provided by other manufacturers. The manufacturer is not liable for damage caused to other machines or equipment that result from the use of this machine. The manufacturer reserves the right to develop or modify the construction of the machine. The owner of the machine is responsible for ensuring that all operators of the machine acquaint themselves with the machine's operating and safety instructions.

1.5. Tightening torques

The table below shows the tightening torques of steel screws and nuts. If the tightening torque to be used should be something other than what is listed in the table, the tightening torque will be provided with the task instructions.

Table. 1.5. - 5. Tightening torques of steel screws and nuts

Steel screws and nuts: 8.8 Zn	
Thread	Torque (Nm)
M8	15
M12	90
M16	230
M18	250
M20	350









2. Warranty terms






1. The machine's warranty period is 12 months.
2. The warranty period starts on the date when an authorised retailer delivers the machine.
3. The warranty covers manufacturing and raw material defects. Damaged parts are repaired or replaced with parts in proper operating condition at the customer's facilities, factory or authorised repair shop.
4. A warranty repair does not extend the warranty period.
5. Warranty does not cover:
 - damage caused by incorrect operation or maintenance in violation of the operating manual, excessive loading or normal wear.
 - loss of income, downtime, other consequential or indirect damage caused to the product's owner or a third party
 - travel or freight expenses, daily allowances
 - changing the original construction of the product.








In warranty matters, please contact the machine retailer or manufacturer. Any measures and costs must always be agreed upon with the manufacturer before the measures are taken.



3. Safety instructions

3.1. Residual risks




	Read this operating and maintenance manual thoroughly before operating the machine and follow the instructions given.
	Crushing hazard when connecting and disconnecting the seed drill. Minimum safe distance 5 m. Exercise extreme caution when someone else is near the seed drill and tractor giving instructions on connecting and disconnecting.
	Crushing and impact hazard when lifting and lowering the middle markers. When lifting and lowering the markers, make sure there is no one in the vicinity. The minimum safe distance is 5 m when lifting and lowering the machine. Before performing the calibration test, ensure that the middle marker ball valves are closed.
	Crushing and impact hazard when lifting and lowering the middle markers. When lifting and lowering the markers, make sure there is no one in the vicinity. The minimum safe distance is 5 m when lifting and lowering the machine.
	Crushing hazard when the accessories are being adjusted. Before adjusting the accessories, make sure that the tractor is turned off, the key is removed from the ignition and the parking brake is engaged.
	Be careful not to crush or cut your hand or fingers in the feeder of the hopper. Ensure that the controller and tractor are turned off, the key is removed from the ignition and the parking brake is engaged when there are personnel in the hopper or near the machine.
	Crushing hazard under the machine and crushing and cutting hazard in the machine transmission when performing servicing and maintenance. Before servicing, make sure that the tractor is turned off, the key is removed from the ignition and the parking brake is engaged.
	Crushing hazard when lifting and lowering the seed drill. When lifting and lowering the machine, make sure there is no one in the vicinity. Minimum safe distance 5 m. Crushing hazard when performing servicing and maintenance. Before servicing, ensure that stoppers have been placed on the cylinder rods and that the machine has been supported from underneath with a block or similar. Never go under a machine that is not securely propped up.


	<p>Hydraulic hoses under pressure may release a life-threatening jet of liquid. High-pressure liquid may also pose a crushing, cutting or impact hazard.</p> <p>The hydraulic system must be depressurised before pressure hoses are handled, connected or disconnected. Depressurise the hydraulic system and disconnect the hoses before maintenance work.</p> <p>Never touch the hydraulic cylinders, hoses and hydraulic connectors when the cylinders are in operation.</p>
	<p>Falling hazard when performing work on the platform. Accessing the steps of the platform is allowed only when the machine is lowered. Exercise caution when performing work on the platform.</p>
	<p>Falling hazard. Standing or sitting on top of the machine, wheels and sensors is always prohibited.</p>
	<p>Before moving and servicing, ensure that the middle markers have settled into the transport position and that their ball valves are closed.</p>
	<p>Before performing a calibration test, ensure that the tractor's parking brake is engaged, the middle markers have settled into the transport position and their ball valves are closed.</p>


	<p>Crushing hazard when lifting the seed drill from a truck bed using a hoist. Minimum safe distance 10 m. Exercise extreme caution.</p>
	<p>Crushing or cutting hazard when installing the drawbar, front equipment, rear harrow, middle markers and drawbar cylinder. Exercise special caution.</p>
	<p>Before moving, ensure that the tractor hitch is locked.</p>
	<p>Crushing and cutting hazard when removing the wheels. Exercise caution when handling the wheels.</p>
	<p>Depressurise the hydraulic system, disconnect the hoses and tractor's electrical connections and let the machine cool off before servicing.</p>
	<p>Avoid breathing seed dressing dust and fertiliser dust when filling the hopper. The seed dressing causes a serious health risk. Read the material safety data sheet of the dressing agent and fertiliser and follow their warnings.</p>
	<p>Never go under a lifted load when filling the hopper.</p>


	Make sure that nobody is on top of the seed drill or inside the hopper when filling the hopper.
	Wear protective gloves when handling oil or grease and when connecting and disconnecting hydraulic components. Avoid skin contact with oil and grease to prevent skin irritation and damage.


3.2. Symbols used in the operating manual


	DANGER warns of a dangerous situation which may result in death or serious physical injury.
	NOTE warns of a dangerous situation which may lead to damage to the equipment.
	ADVICE contains useful tips, advice and information in the instructions e.g. on tightening torques, adjusting values, liquid quantities and special tools.

 **DANGER**
When connecting and disconnecting hydraulic hoses and electrical wires, ensure that the tractor is turned off and the key is removed from the ignition.


 **DANGER**
Never adjust or clean a moving seed drill.

 **DANGER**
Never stand or sit on top of the seed drill or within its operating area during operation. Minimum safe distance 5 m.

 **DANGER**
Inspect the condition of the seed drill at least visually before moving or operating it. Items to be inspected include tyre pressure, machine cleanliness and the tightness of the bolts of the towing device.

 **DANGER**
Before seeding, make sure that the machine is in working order. Make sure that the hoses are intact and have no leaks. Make sure that the coulters and mechanics are intact. Specifically ensure that all the pins are in place.

 **DANGER**
When transporting the seed drill on public roads, exercise caution and observe all road traffic regulations, as well as specific regulations concerning slow-moving vehicles.

 **DANGER**
Before moving the tractor, check that the slow-vehicle triangle is visible and tractor lights are lit and visible. Keep the triangle and lights clean, because they have a considerable impact on the combination vehicle's traffic safety.



DANGER

The maximum allowed transportation speed of the seed drill is 40 km/h on a road that is even and in good condition. The maximum allowed transportation speed of the seed drill is 25 km/h on damaged roads



DANGER

When replacing hydraulic system components and conductors, only use spare parts with sufficient pressure resistance.



DANGER

Never use oil or lubrication grease to clean skin. These substances may contain small metal particles, which cause irritation of the skin or cuts. Follow the lubricant manufacturer handling instructions and safety regulations. Synthetic oils are often corrosive and cause severe irritation of the skin. Seek medical attention if oil or grease causes any injuries.



DANGER

Never spray water directly on electric equipment.



CAUTION

Before servicing, ensure that the machine lifting ball valve is closed and the cylinders are equipped with stoppers.



CAUTION

Use original machine spare parts whenever servicing and repairing the seed drill. Using generic parts will void the warranty.



CAUTION

Collect oil waste and dispose of it appropriately in accordance with national regulations.



CAUTION

If oil is spilled on the ground, absorb it with an absorbent material, such as turf, to prevent the oil spill from spreading. Handle the absorbent material in accordance with regulations.



CAUTION

Clean the machine whenever you change fertiliser or seed types.



CAUTION

If the machine will be unused overnight or over a long rain season, empty its fertiliser hopper in advance and clean the roller grooves of the feeder by adjusting the feed rate from one extreme position to the other. Otherwise, the fertiliser may dissolve and clog the feeders.



CAUTION

Before using a detergent, make sure it is appropriate for washing a seed drill. Follow the safety and operating instructions of the detergent manufacturer.

3.3. Warning labels used on the machine




Figure. 3.3. - 2. Labels on the seed drill drawbar and front

Table. 3.3. - 6. Labels on the seed drill drawbar and front

1.	Hydraulic connection of the drawbar adjustment (optional)	1 pcs
2.	Hydraulic connection of the coulters pressure	1 pcs
3.	Machine lifting hydraulic connection	1 pcs
4.	Hydraulic connection of the adjustment of the front levelling board position	1 pcs
5.	Coulters pressure scale	1 pcs
6.	Crushing when connecting and disconnecting the seed drill - minimum safety distance 5 m.	1 pcs
7.	Cutting hazard	1 pcs
8.	Before adjusting the seeding depth and accessories, make sure that the tractor is turned off, the key is removed from the ignition and the parking brake is engaged.	1 pcs

9.	Beware of pressurised hydraulic hoses	1 pcs
10.	Ensure that the tractor's parking brake is engaged and the marker ball valve is in the closed position before performing the calibration test. Ensure that the markers have settled in the transport position and their ball valves have been closed before moving.	1 pcs
11.	Read the operation and maintenance manual carefully before operation	1 pcs




Figure. 3.3. - 3. Right side labels of the seed drill

Table. 3.3. - 7. Right side labels of the seed drill

1.	Falling hazard, do not climb on top of the wheel	2 pcs, at both ends of the working platform
2.	Falling hazard	2 pcs, at both ends of the working platform
3.	Crushing and impact hazard when lifting and lowering the middle markers	2 pcs, on both middle markers
4.	Adjustment direction, increases clockwise	1 pcs
5.	Adjustment direction, increases counterclockwise	1 pcs
6.	Cutting hazard	2 pcs, on both sides of the machine

7.	Crushing hazard	2 pcs, on both sides of the machine
8.	Scale of the adjustment disc, clockwise number sequence	1 pcs
9.	Scale of the adjustment disc, counterclockwise number sequence	1 pcs
10.	Crushing hazard when performing servicing and maintenance.	2 pcs, on both sides of the machine




Figure. 3.3. - 4. Left side warning labels of the seed drill

Table. 3.3. - 8. Left side warning labels of the seed drill

1.	Crushing and impact hazard when lifting and lowering the middle markers	2 pcs, on both middle markers
2.	Adjustment of coulter depth	1 pcs
3.	Crushing hazard	2 pcs, on both sides of the machine
4.	Cutting hazard	2 pcs, on both sides of the machine
5.	Crushing hazard when performing servicing and maintenance.	2 pcs, on both sides of the machine




Figure. 3.3. - 5. Left side seeding and control labels of the seed drill

Table. 3.3. - 9. Left side seeding and control labels of the seed drill

1.	Seeding quantities	1 pc, underneath the transmission cover
2.	Adjustment scale	None (0 pcs) in a machine without a gearbox 1 pc in a machine with a gearbox on the seed side 2 pcs in a machine with a dual gearbox
3.	Product calibration	1 pc
4.	Rotation direction of the calibration test and number of rotations	1 pc




Figure. 3.3. - 6. Labels, reflectors and lights in rear of seed drill

Table. 3.3. - 10. Labels, reflectors and lights in rear of seed drill

1.	Crushing and impact hazard when lifting and lowering the rear markers	2 pcs
2.	Rear lights	2 pcs
3.	Reflectors	2 pcs
4.	Warning tape	2 pcs
5.	Plate slow vehicle	1 pcs




Figure. 3.3. - 7. Seed drill hopper

Table. 3.3. - 11. Markings on the seed drill hopper

1.	Hopper fill level, markings at 100 litre intervals, scale up to 500 litres	2 pcs
----	--	-------




Figure. 3.3. - 8. Overhead view of the seed drill

Table. 3.3. - 12. Overhead view of the seed drill

1.	Label indicating the location of the operation manual	1 pc
2.	Warning tape	2 pcs, on both markers of the machine
3.	Label indicating the transmission oil to use, only in models equipped with a transmission	1 pc




Figure. 3.3. - 9. Front platform labels

1.	Falling hazard	2 pcs, on both ends of the front platform
----	----------------	---

3.4. Using the middle marker ball valves




Figure. 3.4. - 10. Middle marker ball valves



DANGER

There is a crushing and impact hazard when lowering the middle markers. Close the 2 middle marker ball valves (2) before moving, running a calibration test and servicing.

- The ball valve of the middle marker is closed when the handle (1) is perpendicular to the hydraulic hose (A).
- Open the 2 middle marker ball valves (4) when moving the machine into its working position.
 - The ball valve of the middle marker is open when the handle (3) is parallel with the hydraulic hose (B).

4. Control systems

One of the following controller types must be selected for the seed drill:

- Lykketronic area counter
- Comfort control system
- SeedPilot control system
- SeedPilot ISOBUS control system

These instructions describe the Lykketronic area counter and the Comfort control system.

4.1. Lykketronic area counter

4.1.1. Counter components




Figure. 4.1.1. - 11. Area counter components

1.	Display
2.	1 m cable
3.	M12 female connector
4.	5 m connecting cable
5.	M12 male connector
6.	3 m cable
7.	Sensor
8.	Magnet




Figure. 4.1.1. - 12. Area counter

The sensor (2) and the magnet (1) have been installed behind the transmission. The 3-metre cable (4) is connected to the machine frame. The 5-metre connecting cable (3) is connected to the 3-metre cable.

4.1.2. Counter buttons and display




Figure. 4.1.2. - 13. Area counter

1.	Display
2.	SET key
3.	C key

Table. 4.1.2. - 13. Display symbols

Symbol displayed	Function
HA.1	Area I, partial area
HA.2	Area I, total area
- - - -	Working width
o	Advance

4.1.3. Using the counter

4.1.3.1. Setting the machine's working width

- The working width setting is 3.00 m. Enter the working width in metres.
1. Press the C key repeatedly until the working width symbol | - - - | is displayed on the screen.
 2. Press the SET key.
 - The first number starts to flash. The number can now be changed.
 3. Press the C key repeatedly until the value is _.
 4. Press the SET key, and the second number starts to flash. Press the C key repeatedly until the value is 3.
 5. Press the SET key, and the third number starts to flash. Press the C key repeatedly until the value is 0.
 6. Press the SET key, and the fourth number starts to flash. Press the C key repeatedly until the value is 0.

4.1.3.2. Setting the value of advance

- The advance is set to 150.0 cm. The value is entered in centimetres.
1. Press the C key repeatedly until the advance symbol o is displayed on the screen.
 2. If the position of the comma must be changed, press and hold the SET key for approximately 2 seconds until the comma starts to flash. Press the C key until the comma is in the correct position.
 3. Press the SET key.
 - The first number starts to flash. The number can now be changed.
 4. Press the C key repeatedly until the value is 1.
 5. Press the SET key, and the second number starts to flash. Press the C key repeatedly until the value is 5.
 6. Press the SET key, and the third number starts to flash. Press the C key repeatedly until the value is 0.
 7. Press the SET key, and the fourth number starts to flash. Press the C key repeatedly until the value is 0.

4.1.3.3. Resetting the area counter

1. Press the C key repeatedly until the area symbol HA.1 and the area value are displayed on the screen.
2. Press and hold the SET key for approximately 2 seconds until the area value starts to flash.
3. Press the C key repeatedly until the value is reset.

4.1.3.4. Switching power on and off

- The device is powered by two 1.5 V AA batteries.
The device starts operating when it receives a signal from the sensor.
1. Switch the device on manually by pressing the SET or C key.
 - The display shows the number of the program version.
The device checks the condition of the batteries. If the display shows text "-bL" and the device switches off, change the batteries. If text "-bL" flashes during use, the battery voltage starts to decrease and the batteries should be changed.
The device switches off automatically if it has not received a pulse from the sensor for 0.5 - 1.5 hours or if no key has been pressed. All values are stored in the memory.
 2. Switch the device off manually by pressing and holding the C key for approximately 4 seconds.
 - The display shows text "stop" for approximately one second, after which the device switches off.

4.2. Comfort control system

4.2.1. Control system components

4.2.1.1. Speed sensor




Figure. 4.2.1.1. - 14. Speed sensor

The speed sensor (1) calculates the speed of the seed drill and the area seeded. The Comfort controller system display shows the driving speed and the area seeded. The speed sensor and the seeding position sensor together also indicate that the transmission works. If the machine is in the seeding position and the seed shaft does not rotate, an alarm will be triggered in the controller within 7 seconds.

4.2.1.2. Seeding position sensor




Figure. 4.2.1.2. - 15. Seeding position sensor

The seeding position sensor (1) recognises when the machine is in the transport or seeding position. If the machine is in the seeding position and the seed shaft does not rotate, an alarm will be triggered in the controller within 7 seconds.

The seeding position sensor also works as a counter. In the normal operation of the lift inhibit function, the counters and switching of the middle marker side will be operational at each lifting. See section [6.3.1. Active operating mode](#).

4.2.1.3. Hopper level sensors




Figure. 4.2.1.3. - 16. Hopper level sensors

The hopper level sensors (1) are capacitive sensors located in the hopper. As a standard feature, there are two hopper level sensors in the machine: one in the seed hopper and one in the fertiliser hopper on the left side of the machine. Hopper level sensors are also available as an accessory for the right-hand side hoppers of the machine, in which case the total number of hopper level sensors will be 4. If the seed or fertiliser level in the hopper is too low, an alarm is triggered in the Comfort control system.

4.2.1.4. Tramline clutches




Figure. 4.2.1.4. - 17. Tramline clutches

The tramline clutches (1) are located on both sides of the feeder unit. The clutches have been installed on both the seed and the fertiliser side. The total number of tramline clutches in the machine is 4. The clutch can be used to disconnect one feeder.




Figure. 4.2.1.4. - 18. Notched feeder roller

The tramline clutch comes with one notched feeder roller (1) as a standard feature. When the tramline clutch is powered on, the notched feeder roller does not rotate. During the seeding operation, a tramline is generated when a row is not seeded.

Shaft rotation guards are built into the tramline clutch.

4.2.1.5. Tramline clutch extensions




Figure. 4.2.1.5. - 19. Tramline clutch extensions

The tramline clutch comes standard with one notched feeder roller; see section [4.2.1.4. Tramline clutches](#). The extension pack includes a notched feeder roller (1) and two sleeves (2,3). When the tramline clutch is powered on, the notched feeder rollers do not rotate.

4.2.1.6. Linear actuator for remote control




Figure. 4.2.1.6. - 20. Linear actuator for remote control. On the left, a machine without a gearbox and, on the right, a machine equipped with a gearbox on the seed side. On the right, a machine with a dual gearbox.

A LINAK linear actuator (3, 6) is used for remote control. A pointer (2, 5) indicates the fertiliser feed rate on a scale of (1, 4). The feed rate scale on the linear actuator describes the relative value of the fertiliser feed rate.

In machines without a gearbox or with one gearbox on the seed side, the linear actuator is found in the feeder unit (figure on the left). In machines with a dual gearbox, i.e. a gearbox on both the seed and fertiliser side, the linear actuator is found in the transmission (figure on the right).

4.2.2. Comfort controller buttons




Figure. 4.2.2. - 21. Controller buttons

1.	<p>Switching power on and off</p> <ul style="list-style-type: none"> The controller switches off when the button is held down for 3 seconds. <p>Activating the lift inhibit function</p> <ul style="list-style-type: none"> See section 6.3.1. Active operating mode
2.	<p>Selecting the middle marker function</p> <ul style="list-style-type: none"> See section 6.3.2. Using the middle markers.
3.	<p>Arrow buttons (4): up, down, left and right</p>
4.	<p>Stopping the tramline counter</p> <ul style="list-style-type: none"> See section 6.3.3. Using the tramline counter.
5.	<p>Changing the page</p> <ul style="list-style-type: none"> When on the MAIN screen of the user interface, go to the next screen (SHFT) by holding down the button for 3 seconds. When on the SHFT, INFO or Setup screen, go to the next screen by pushing the button once. The screen number is shown on the right side of the screen. An icon appears on each screen. <p>Adding a tramline counter</p> <ul style="list-style-type: none"> See section 6.3.3. Using the tramline counter.

4.2.3. User interface

MAIN: the main display




Figure. 4.2.3. - 22. MAIN: the main display

1.	Active position and operation of the middle markers <ul style="list-style-type: none"> See section 6.3.2. Using the middle markers
2.	Driving speed
3.	Active value of area measurement
4.	Fertiliser remote control target rate
5.	Mode and counter of tramline clutches <ul style="list-style-type: none"> See section 6.3.3. Using the tramline counter
6.	User interface screen number

SHFT: adjustment and rotation tab




Figure. 4.2.3. - 23. SHFT: adjustment and rotation tab

1.	Fertiliser remote control settings <ul style="list-style-type: none"> See section 6.3.5. Selecting the setting method for adjusting of fertiliser target rate
2.	Rotation speed of seed and fertiliser feed shafts

INFO: counter tab




Figure. 4.2.3. - 24. INFO: counter tab

1.	Total area sown
2.	Work time
3.	Average work rate performed (ha/h)

- Instructions on use of the area counter use can be found in section [6.3.6. Area counter use](#)

Setup screen



Figure. 4.2.3. - 25. Setup screen

1.	Product calibration
2.	User setup
3.	Factory setup
4.	Diagnostics

4.2.4. Using the user interface

4.2.4.1. User setup




Figure. 4.2.4.1. - 26. User interface Setup screen

- Use the up/down arrow buttons to scroll through the menu (3). Press the ESC button (2) to return to the previous screen.

1. Move the cursor to User setup (1) and open the screen by pressing the OK button (4).



Figure. 4.2.4.1. - 27. User setup

1.	Display <ul style="list-style-type: none"> • Adjusting the display brightness
2.	Customisation <ul style="list-style-type: none"> • Adjusting the fertiliser remote control target rate step
3.	Time/date <ul style="list-style-type: none"> • Time and date setting

4.	<p>Technical support</p> <ul style="list-style-type: none"> • Technical support contact details
5.	<p>Language</p> <ul style="list-style-type: none"> • Language selection
6.	<p>Seed drill</p> <ul style="list-style-type: none"> • Setting the seed drill parameters
7.	<p>Tramlines</p> <ul style="list-style-type: none"> • Setting tramlines
8.	<p>Alarms</p> <ul style="list-style-type: none"> • Setting alarms

Adjusting the fertiliser remote control target rate adjustment step



Figure. 4.2.4.1. - 28. Adjusting the fertiliser remote control target rate adjustment step

1. Press the OK button (1).
2. Set the new target rate adjustment step using the up/down arrow buttons. Confirm the target rate adjustment step by pressing right arrow button.
3. Accept the step value by pressing the OK button (1).

Seed drill parameters




Figure. 4.2.4.1. - 29. Seed drill parameters

1.	Seed drill width <ul style="list-style-type: none"> • 3 m or 4 m
2.	Speed sensor <ul style="list-style-type: none"> • The factory setting is 0.214 • See section 7.10.1. Manual calibration of the speed sensor.
3.	Speed sensor calibration <ul style="list-style-type: none"> • See section 7.10.2. Calibration of the speed sensor while driving.
4.	T Factor <ul style="list-style-type: none"> • Electric fertiliser control calibration value, which varies according to the calibration test result. • Cannot be changed in this screen.

Setting the tramline automation




Figure. 4.2.4.1. - 30. Setting tramlines

- The number of passes (4) and location of tramlines can be set in two ways. The seed drill width (1) and the width of the sprayer used (2) is displayed on the screen.
1. Select the number of passes (4) using the up/down arrow buttons.
 - If the machine is to be run without tramlines, select '0' for the number of tramlines. In this case, the tramlines are not used, but the middle markers will change sides.
We recommend using the method below, which will make it possible to begin seeding from the edge of the field on the first pass.
 2. Press the right button (3).




Figure. 4.2.4.1. - 31. Setting the number of passes and selecting tramlines

3. Set the number of passes (Count) (1) using the arrow buttons.
4. Press the SET button (3).
 - The pass (Bout) (2) number begins to flash.
5. Press the SET key.
6. Select the tramlines to be used with the right and left arrow buttons.
 - When the tramlines are used on a pass, a checkmark appears on the screen (4).
When the tramlines are not used on a pass, an 'X' appears on the screen.
7. Press the SET button until all the passes have been made.
 - The system returns to the previous screen. The old setting appears on the screen, even though a new one has been entered.




Figure. 4.2.4.1. - 32. Tramlines

- The width of the pass is the same as the width of the seed drill (1). In this case, the width of the seed drill is 4 m and the number of passes is 5, this making the spray width (4) 20 m. Tramlines are made on the third pass.

Setting alarms




Figure. 4.2.4.1. - 33. Alarms

1.	Seed hopper level sensor <ul style="list-style-type: none"> • The alarm is triggered when the seed hopper is empty.
2.	Fertiliser hopper level sensor <ul style="list-style-type: none"> • The alarm is triggered when the fertiliser hopper is empty.

3.	<p>Shaft rotation guard - seed</p> <ul style="list-style-type: none"> The alarm is triggered when the shaft stops but the transmission keeps running.
4.	<p>Shaft rotation guard - fertiliser</p> <ul style="list-style-type: none"> The alarm is triggered when the shaft stops but the transmission keeps running.
5.	<p>Tractor speed</p> <ul style="list-style-type: none"> The alarm is triggered when the seed drill is in the working position and the tractor is not moving. The driving speed begins to flash on the MAIN screen.
6.	<p>X:1</p> <ul style="list-style-type: none"> Disabled. The alarm is not activated.
7.	<p>Voltage</p> <ul style="list-style-type: none"> The alarm is triggered when the voltage falls below 9 V.



Figure. 4.2.4.1. - 34. Selecting alarms

- Use the up/down arrow buttons to scroll through the menu.
1. Enable or disable the alarm with the right arrow button.
 2. Confirm the selection by pressing the OK button (1).

5. Commissioning and basic settings

5.1. Rendering to operating condition

5.1.1. Mounting the wheel packer

- The wheel packer is an accessory.

DANGER



The mounting of the wheel packer requires two people.

DANGER



Use a hoisting accessory when mounting the wheel packer.

DANGER



Lift and mount the wheel packer only when the machine is on a level surface.




Figure. 5.1.1. - 35. Lifting the wheel packer

1. Place the wheel packer (1) to the centreline and to the front of the machine and attach the lifting sling (1) to the cylinder bracket (2).

DANGER



Ensure that the capacity of the lifting sling and the lifting device is sufficient. The wheel packer weighs 250 kg.

2. Lift the bar and align it with the attachment points.




Figure. 5.1.1. - 36. Mounting the wheel packer

3. Place the washer (1) against the inner shoulder of the attachment points and insert the mounting pin (2) through the shoulders and the mounting cylinder of the bar.
4. Lock the mounting in place with a spring cotter.
5. Repeat steps 3-4 for the second attachment point.




Figure. 5.1.1. - 37. Hydraulic hoses and electrical wires

6. Open the fastening screw (3) of the tube mounts and remove the top (4).
7. Draw the hydraulic hoses through the guide (1) and on both sides of the cylinder bracket (2).
8. Use cable ties to fasten the hoses on both sides of the cylinder bracket.
 - Do not tighten the cable ties to the final tightness.
9. Place the hoses in the tube mounts and fasten the top of the tube mounts and the fastening screws.




Figure. 5.1.1. - 38. Connecting the hydraulic hoses

1.	Green, one mark	Drawbar cylinder, cylinder extend
2.	Green, two marks	Drawbar cylinder, cylinder retract
3.	Blue, one mark	Coulter pressure, decreasing the coulter pressure
4.	Blue, two marks	Coulter pressure, increasing the coulter pressure
5.	Red, one mark	Vertical movement of the seed drill, cylinder extend
6.	Red, two marks	Vertical movement of the seed drill, cylinder retract

10. Connect the hydraulic hoses 3-6.

- Connect the hydraulic hoses of the drawbar cylinder only when the drawbar cylinder is installed.

11. Push the hoses back towards the drawbar to eliminate slack and tighten the tube mounts and cable ties.

12. Attach the electrical wires contained in a protective tube to the hydraulic hoses with cable ties and guide the wires on the right side of the seed drill (viewed from the front).

13. Check the drawbar cylinder in accordance with section 5.1.2. Mounting the drawbar cylinder.

5.1.2. Mounting the drawbar cylinder

- The drawbar cylinder is an accessory. The drawbar cylinder is supplied with the wheel packer but it can also be used without the wheel packer.




Figure. 5.1.2. - 39. Drawbar cylinder

Number	Component	Quantity
1.	Locking pin Ø8x71	2 pcs
2.	Pin Ø45x110	2 pcs
3.	Washer M45	4 pcs

1. Replace the washer (3) and fasten the drawbar cylinder to the seed drill with a mounting pin (2).
2. Lock the mounting pin in place with the cotter (1).
3. Repeat steps 1-2 for the second attachment point of the cylinder.

5.1.3. Attaching the turnbuckle




Figure. 5.1.3. - 40. Turnbuckle

Number	Component	Quantity
1.	Pin Ø45x110	2 pcs
2.	Washer M45	4 pcs
3.	Locking pin Ø8x71	2 pcs

1. Replace the washer (2) and fasten the turnbuckle to the seed drill with a mounting pin (1).
2. Lock the mounting pin in place with the cotter (3).
3. Repeat steps 1-2 for the second attachment point of the turnbuckle.

5.1.4. Mounting the front levelling board

- The front levelling board is an accessory. Using the front levelling board requires that an wheel packer be installed.

DANGER

The mounting of the front levelling board requires two people.



DANGER

Use a hoisting accessory when mounting the front levelling board.






Figure. 5.1.4. - 41. Lifting the front levelling board

1. Fasten lifting slings (1) around the tube (2).



DANGER

Ensure that the capacity of the lifting sling and the lifting device is sufficient. The front levelling board weighs 250 kg.

2. Follow the mounting instructions for the Cerex 300 or Cerex 400

Mounting the front levelling board on a Cerex 300




Figure. 5.1.4. - 42. Mounting the front levelling board on a Cerex 400

Number	Component	Quantity
1.	Hex screw M24x60	5 pcs
2.	Washer M24	16 pcs
3.	Locking nut M24	8 pcs
4.	Hex screw M24x75	3 pcs
5.	Shim	1 pcs

1. Raise the front levelling board using lifting slings and push it under the wheel packer drawbar all the way to the machine frame.
2. Attach the front levelling board to the machine frame using components (1-5).
 - The front levelling board is mounted to the frame at 3 mounting points. Place a shim between the front levelling board and the machine frame at the mounting point on the left (as seen from the front of the machine).

Mounting the front levelling board on a Cerex 400




Figure. 5.1.4. - 43. Mounting the front levelling board on a Cerex 400

Number	Component	Quantity
1.	Hex screw M24x60	7 pcs
2.	Washer M24	26 pcs
3.	Locking nut M24	13 pcs
4.	Hex screw M24x75	3 pcs
5.	Shim	5 pcs
6.	Hex screw M24x120	3 pcs

1. Raise the front levelling board using lifting slings and push it under the wheel packer drawbar all the way to the machine frame.
2. Attach the front levelling board to the machine frame using components (1-6).
 - The front levelling board is mounted to the frame at 5 mounting points. Place a shim between the front levelling board and the machine frame at the second mounting point (as seen from the left of the machine). Place 4 shims between the front levelling board and the machine frame at the centre mounting point.

5.1.5. Mounting the middle markers

- The middle markers are an accessory.




Figure. 5.1.5. - 44. Mounting the middle markers

Number	Component	Quantity
1.	Hex screw M8x100	2 pcs
2.	Washer M8	4 pcs
3.	Locking nut M8	2 pcs
4.	Locking nut M20	2 pcs
5.	Washer M20	2 pcs
6.	Hex screw M20x110	2 pcs

1. Mount the markers on the marker axle on both sides of the seed drill by using components (1-6).

- Tighten the bolts of the markers so that there is no clearance.

5.1.6. Removing the transport supports

- Once the front accessories have been mounted in the seed drill, the seed drill can be connected to the tractor in accordance with section [5.3. Connecting to tractor](#) and the seed drill transport supports can be removed.




Figure. 5.1.6. - 45. Transport support

1. Open the three transport support bolts (1) and detach the transport supports (2) from both sides of the seed drill.

5.1.7. Mounting the scraper

- The scraper is an accessory.




Figure. 5.1.7. - 46. Mounting the scraper

Number	Component	Quantity
1.	Hex screw M16X50	6 pcs
2.	Washer M16	12 pcs
3.	Scraper mounting plate	2 pcs

4.	Locking nut M16	6 pcs
5.	Washer M16	16 pcs
6.	Locking nut M16	8 pcs
7.	Plate	2 pcs
8.	Hex screw M16x110	8 pcs

1. Set the scraper mounting plate (3) into place and fasten it by using washers (2), hex screws (1) and locking nuts (4).
2. Repeat step 1 for the second mounting plate.
3. Fasten the plate with washers (5), hex screws (8) and locking nuts (6).
4. Repeat step 3 for the second plate.

5.1.8. Mounting the rear harrow

- The rear harrow is an accessory.



DANGER

The mounting of the rear harrow requires two people.



DANGER

Use a hoisting accessory when mounting the rear harrow.




Figure. 5.1.8. - 47. Mounting the rear harrow arms

Number	Component	Quantity
1.	Locking nut M20	2 pcs
2.	Washer M20	4 pcs
3.	Hex screw M20x180	2 pcs
4.	Hex screw M24x55	2 pcs
5.	Hex nut M24	2 pcs

1. Attach the rear harrow arms to the seed drill with components (1-5).
 - Tighten the bolts of the rear harrow arms so that there is no clearance.




Figure. 5.1.8. - 48. Attaching the rear harrow chains

2. Attach the chains (2) to the working platform of the seed drill with shackles (1, 3).




Figure. 5.1.8. - 49. Lifting the rear harrow

3. Tie a lifting sling (1) around the tube (2).



DANGER

Ensure that the capacity of the lifting sling and the lifting device is sufficient. The rear harrow weighs 100 kg.




Figure. 5.1.8. - 50. Mounting the rear harrow

Number	Component	Quantity
1.	Washer M20	4 pcs
2.	Hex screw M20x60	2 pcs
3.	Rear harrow arm	2 pcs
4.	Tube	1 pcs
5.	Locking nut M20	2 pcs
6.	Clamp	2 pcs

4. Use a lifting sling to raise the tube (4) of the rear harrow and position the tube so that the rear harrow arms (3) are between the clamps (6).
5. Attach the rear harrow tube to the rear harrow arms by fastening the clamp with washers (1), a hex screw (2) and a locking nut (5).
 - Tighten the bolts of the rear harrow so that there is no clearance.
6. Repeat step 5 for the other clamp.

5.1.9. Mounting the rear markers on the rear harrow

- The rear markers are an accessory.
- DANGER**
Mounting rear markers requires two people.



DANGER
Use hoisting equipment when mounting the rear markers.




Figure. 5.1.9. - 51. Lifting the rear markers

1. Attach a lifting sling (1) around the marker frame (2).



DANGER

Ensure that the capacity of the lifting sling and the lifting device is sufficient. The rear markers weigh 75 kg.

2. Lift the rear markers with a lifting sling (1) through the frame (2) and place the frame so that the rear marker arms (3, 5) are between the front levelling board actuating arms (4, 6).




Figure. 5.1.9. - 52. Mounting the rear markers on the rear harrow

Number	Component	Quantity
1.	Locking nut M16	4 pcs
2.	Washer M16	8 pcs
3.	Hex screw M16x70	4 pcs
4.	Hex screw M20x70	2 pcs
5.	Washer M20	4 pcs
6.	Washer M20	4 pcs
7.	Locking nut M20	2 pcs

3. Attach the rear markers to front levelling board actuating arms with washers (2, 5, 6), hex screws (3, 4) and locking nuts (1, 7).
4. Repeat step 3 for the second attachment point.




Figure. 5.1.9. - 53. Mounting rear marker cylinders

Number	Component	Quantity
1.	Pin Ø24	4 pcs
2.	Washer M24	4 pcs
3.	Linchpin	4 pcs

5. Pick up the cylinder from the working platform and mount it to the actuating arm with pins (1) and washers (2).
6. Lock the mounting pin in place with the linchpin (3).
7. Repeat steps 5-6 for the second cylinder.

5.1.10. Turning the rear railing of the working platform and attaching the end railing




Figure. 5.1.10. - 54. Turning the rear railing of the working platform

Number	Component	Quantity
1.	Rear railing	1 pcs
2.	Locking nut M8	8 pcs
3.	Washer M8	8 pcs
4.	U-bolt	4 pcs

- For transport, the rear railing (1) of the working platform has been turned inward.
1. Open the bolts of the rear railing of the working platform.
 2. Turn the railing outward and attach it to the working platform with washers (3), U-bolt (4) and locking nuts (2).
 3. Repeat step 2 for all attachment points of the rear railing.




Figure. 5.1.10. - 55. Attaching the end railing of the working platform

Number	Component	Quantity
1.	Locking nut M8	4 pcs
2.	Washer M8	4 pcs
3.	U-bolt	2 pcs

4. Attach the end railing with washers (2), U-bolt (3) and locking nuts (1).
5. Repeat step 4 for the second attachment point.

5.2. Commissioning

5.2.1. Installing the Lykketronic area counter




Figure. 5.2.1. - 56. Installing the area counter

1. Connect the 5-metre cable (3) to the 1-metre cable (1) with connector M12 (2).

- The 5-metre connecting cable is connected to the tractor cabin. Fasten the cable properly so that it is not pinched during turns or lifting.




Figure. 5.2.1. - 57. Fastening the area counter

2. Fasten the display counterpart (4) to the metal plate (3) with the two fastening screws (5).
3. Attach the metal plate to the cabin from the fastening holes (2) by two fastening screws.
 - Attach the display in a location where view is not obstructed but where the display is easily viewable by turning one's glance while driving. Ensure that the cable is sufficiently long to reach the display fastening spot.
4. Snap the area counter display (1) to the metal plate.

5.2.2. Installing the Comfort control panel




Figure. 5.2.2. - 58. Installing the Comfort control panel

1. Connect the cable (1) of the Comfort control panel to the cable (2) connected to the seed drill.
 - Fasten the cable properly so that it is not pinched during turns or lifting.




Figure. 5.2.2. - 59. Fastening the Comfort control panel

2. Fasten the display bracket (3) to the plate (5) by using a screw (6).
3. Fasten the display bracket (4) to the cabin with two fastening screws (4).
 - Attach the display in a location where view is not obstructed but where the display is easily viewable by turning one's glance while driving. Fasten the display at a suitable height so that the buttons can be reached effortlessly.
4. Fasten the controller display (1) to the display bracket (3) by using a screw (2).

5.3. Connecting to tractor



DANGER

Crushing hazard when connecting and disconnecting the seed drill. The minimum safe distance - 5 m. Exercise extreme caution when there are personnel near the seed drill and tractor giving instructions on connecting and disconnecting.

- Wear protective gloves when connecting the seed drill to the tractor.
1. If the machine is equipped with a wheel packer, adjust the length of the wheel packer drawbar in accordance with section 5.3.1. Adjusting the length of the boom of the wheel packer.
 2. Connect the drawbar of the seed drill to the tractor hitch or the wheel packer draw boom to the tractor's link arms.
 3. Raise the machine with the tractor hydraulics.
 4. Raise the ground support to the top position according to the instructions given in section 5.3.2. Using the ground support.




Figure. 5.3. - 60. Valtra T series hydraulic couplings are provided as a coupling reference

1.	Power Beyond return (back pressure 8 bar)
2.	Power Beyond pressure
3.	LS control
4.	Overflow connector (do not connect a return line)
5.	Free return connector
6.	Double-acting connections 1-4. + function connections
7.	Double-acting connections 1-4. - function connections

5. Connect the hydraulic hoses of the seed drill to the tractor's double-acting spool valve (6, 7).



DANGER





Ensure that the tractor is turned off and the key is removed from the ignition.



DANGER

Hydraulic hoses must be depressurised when connecting them.

- Connect hydraulic hoses in pairs so that the directions of flow are correct. The hydraulic hoses are colour-coded. Check the tractor manual to ensure the hydraulic connections are suitable.

Number	Hydraulic hose	Colour code and symbol
1.	Drawbar adjustment connection <ul style="list-style-type: none"> 2 male connectors of ½" 	
2.	Hydraulic connection of the coulter pressure adjustment <ul style="list-style-type: none"> 2 male connectors of ½" 	
3.	Hydraulic connection for raising the machine to the transport position <ul style="list-style-type: none"> 2 male connectors of ½" 	
4.	Hydraulic connection of the adjustment of the front levelling board position <ul style="list-style-type: none"> 2 male connectors of ½" 	




Figure. 5.3. - 61. Comfort controller power cable DIN 9680

6. If the machine is equipped with a Comfort control system, plug the controller power cable (1) into the tractor cabin plug.



DANGER

Ensure that the tractor is turned off and the key is removed from the ignition.

- Ensure the cable is not crushed by the tractor's rear window. Fasten the cable properly so that it is not pinched during turns or lifting.
7. If necessary, straighten the machine according to the instructions in section [5.3.3. Adjusting the lengthwise level of the machine with a turnbuckle](#) or [5.3.4. Adjusting the lengthwise level of the machine with a drawbar cylinder](#).




Figure. 5.3. - 62. Side stoppers of the tractor link arms

8. Lock the side stoppers (1) of the tractor link arms by inserting the pin (2) to the appropriate hole so that the link arm does not touch the tyres.
9. Open the machine lifting circuit ball valve according to the instructions in section [5.3.5. Using the machine lifting circuit ball valve.](#)
10. Ensure the steerability of the tractor in accordance with the instructions in section [5.3.6. Ensuring the steerability of the tractor.](#)
11. When driving on a field for the first time, set the middle markers according to the instructions given in section [5.3.7. Adjusting the middle markers.](#)

5.3.1. Adjusting the length of the boom of the wheel packer




Figure. 5.3.1. - 63. Adjusting the length of the boom

1. Remove the cotter (1) of the boom mounting pin (2) and pull the mounting pin out of the boom.
2. Adjust the length of the boom (3) so that it is appropriate for the tractor.

- The boom has three adjustment position at 200 mm intervals. The maximum length adjustment is 400 mm.
3. Insert the mounting pin in the boom and lock it in place with the cotter.

5.3.2. Using the ground support




Figure. 5.3.2. - 64. Ground support

1. Remove the cotter (4) of the ground support (3) mounting pin (5) and pull the mounting pin out of the ground support.
2. Move the ground support up or down by the lever (1).
3. Lock the ground support in the mounting hole. Attach the mounting pin and the cotter.
 - The upper mounting hole (2) locks the ground support in the down position. The lower mounting hole locks the ground support in the up position.

5.3.3. Adjusting the lengthwise level of the machine with a turnbuckle

- Perform the adjustment when the machine is on a level surface.




Figure. 5.3.3. - 65. Lengthwise level

- The machine is level when the sidebar (1) of the machine is horizontal.
Connect the seed drill to the tractor in accordance with section [5.3. Connecting to tractor](#).
1. Lower the machine by using the tractor hydraulics.
 2. Switch off power in the tractor, remove the key from the ignition and engage the parking brake.




Figure. 5.3.3. - 66. Adjustment with a turnbuckle

3. Release the locking by turning the plate (1) upward.
4. Turn the turnbuckle (2) by the handle (1) and check visually that the machine is straight.
5. When the machine is straight, turn the plate downward to engage the lock.

5.3.4. Adjusting the lengthwise level of the machine with a drawbar cylinder

- Connect the seed drill to the tractor before adjusting the lengthwise level in accordance with section [5.3. Connecting to tractor](#). The tractor should be on during the adjustment. Perform the adjustment when the machine is on a level surface.




Figure. 5.3.4. - 67. Lengthwise level

- The machine is level when the sidebar (1) of the machine is horizontal.




Figure. 5.3.4. - 68. Cylinder adjustment slats

1. Turn slats (2) over the cylinder (1) shaft.
2. Carefully run the cylinder against the slats and check visually that the machine is straight.
 - If needed, extend the cylinder and add or remove slats, if needed, until the machine is straight.

5.3.5. Using the machine lifting circuit ball valve




Figure. 5.3.5. - 69. Lifting circuit ball valves



DANGER

Close the lifting circuit ball valve (2) before starting out and performing maintenance

- The ball valve of the lifting circuit is closed when the handle (1) is perpendicular to the hydraulic hose (A).

- Open the machine's lifting circuit ball valve (4) after moving the machine into its working position.
 - The ball valve of the lifting circuit is open when the handle (3) is parallel with the hydraulic hose (B).

5.3.6. Ensuring the steerability of the tractor

The calculation of the stability of the tractor - seed drill combination is provided in the attachment *Calculating the stability of the tractor - seed drill combination*. The steering response of a small tractor may be compromised when it pulls the seed drill, because some of the weight of the seed drill rests on the tractor's rear axle. If steering response is weak, we recommend the use of front weights on the tractor. The tractor's weight transfer system should also be switched off, since when using the weight control system, the height of the lifting device may change based on the load and impact the seeding depth.

5.3.7. Adjusting the middle markers




Figure. 5.3.7. - 70. Adjusting the middle markers

1. Loosen the two screws (1).
2. Adjust the width of the marker axle (3).
3. Adjust the toe-in (2) by rotating the disc around the axle (3).
 - The marker should plough a furrow deep enough to be visible in the ground. The distance between the centreline of the seed drill and the furrow made by the middle marker should be 3 metres for the Cerex 300 and 4 metres for the Cerex 400. However, the adjustment is indicative. Check the adjustment in the field to avoid overlapping seeding and stripes according to section [6.14. Securing the position of the middle markers](#). Overlapping seeding and stripes may be generated if the operator sits at an angle in the tractor, for example.
4. Tighten the two screws (1).

6. Machine adjustment and use

6.1. Rendering the machine to the transport position

1. Fold the working platform stairs up.




Figure. 6.1. - 71. Working platform stairs

- The stairs (1) will be at an approximately 40 degree angle to the working platform.
2. Raise the machine with the tractor hydraulics.
 3. If the machine is equipped with middle markers, ensure that the middle markers have settled into their transport position and their ball valves are closed in accordance with section 3.4. Using the middle marker ball valves.
 4. Close the machine lifting circuit ball valve in accordance with section 5.3.5. Using the machine lifting circuit ball valve.
 5. Check the tyre pressure in accordance with section 7.1.3. Checking tyre pressure.
 6. Ensure that the machine is clean.
 - If necessary, clean the machine in accordance with section 7.3. Cleaning.
 7. Visually check that the bolts of the transport wheels are tight in accordance with section 7.1.2.1. Checking the tightness of the wheel bolts of the transport wheels and tighten if necessary.
 8. Check that the bolts of the bearings are tight in accordance with section 7.1.2.2. Checking the tightness of the bolts in the flange bearings of the transport wheels and tighten if necessary.
 9. If the machine is equipped with a standard drawbar, visually check that the bolts of the towing device are tight in accordance with section 7.1.2.6. Checking the tightness of the towing eye bolts and tighten if necessary.




Figure. 6.1. - 72. Wheel packer pins

10. If the machine is equipped with a wheel packer, visually check that the wheel packer pins (1, 2) are closed.
11. If the seed drill is equipped with a standard drawbar, ensure that the tractor hitch is engaged and locked.
12. If the seed drill is equipped with a wheel packer, ensure that the tractor's link arms are locked to the wheel packer.

6.2. Rendering the machine to the working position

1. Open the machine lifting circuit ball valve in accordance with section [5.3.5. Using the machine lifting circuit ball valve](#).
2. If the machine is equipped with middle markers, open the middle marker ball valves in accordance with section [3.4. Using the middle marker ball valves](#).




Figure. 6.2. - 73. Lifting cylinder

3. Lower the lifting cylinders to their lower position using the tractor hydraulics.
 - The Cerex 300 has 1 lifting cylinder (2). The Cerex 400 has 3 lifting cylinders (1-3).

6.3. Comfort control system operating settings

6.3.1. Active operating mode




Figure. 6.3.1. - 74. Active operating mode

- The desired active operating mode (3 options) is selected on the MAIN screen (1) by pressing the controller power button (2).
Normal mode is the default operating mode.

Normal mode




Figure. 6.3.1. - 75. Normal mode

- The machine and middle markers operate normally.
The counters and switching of the middle marker side will be operational whenever lifting.
The function screen number (1) is shown in the bottom left corner of the user interface.
The function infobox (2) will flash on the screen when entering Normal mode.

Lift inhibit mode




Figure. 6.3.1. - 76. Lift inhibit mode

- The machine remains in the seeding position, but the markers are raised. This function is used when the operator wants to avoid an obstacle in front of the middle markers during operation. The function screen number (1) is shown in the bottom left corner of the user interface. The function infobox (2) also flashed on the screen.

Counter stop mode




Figure. 6.3.1. - 77. Counter stop mode

- Corresponds with the Stop tramlines function. See section [6.3.3. Using the tramline counter](#). The tramline counter and middle markers are shut off. Used when filling if the machine has to be lowered. The function screen number (1) is shown in the bottom left corner of the user interface. The function infobox (2) also flashed on the screen.

6.3.2. Using the middle markers

Selecting automatic and manual mode




Figure. 6.3.2. - 78. Selecting automatic and manual mode for middle markers

1. Change the middle marker function by pressing the AUTO-MAN button (1).
 - The middle marker mode is shown on the screen highlighted (2) and (3).

Selecting middle markers



Figure. 6.3.2. - 79. Selecting middle markers

1. Select a middle marker using the arrow buttons.
 - Press the left arrow button to activate the left middle marker. Press the right arrow button to activate the right middle marker. The active middle markers are highlighted (1) on the screen.
In automatic mode, the middle marker will automatically change when the headland is reached. In manual mode, the middle marker is activated and deactivated by pressing the arrow buttons.

6.3.3. Using the tramline counter

Tramline counter correction




Figure. 6.3.3. - 80. Tramline counter correction

- The ADD TRAMLINE COUNTER button (2) can be pressed to add a tramline (1) on drive-around runs or subtract a tramline (1) on back-and-forth runs, if the machine is unintentionally raised one too many times.

1. Add a tramline by pressing the ADD TRAMLINE COUNTER button.
2. Subtract a tramline by pressing the ADD TRAMLINE COUNTER button several times in a row until the correct number of tramlines is set.
 - The number of tramlines will increase at first and then start from 1 again.

Stopping the tramline counter



Figure. 6.3.3. - 81. Stopping the tramline counter

- The tramline counter can be stopped when work is interrupted and when filling the machine. The tramline counter can be stopped when the lift inhibit function is in its normal mode (1/3). See section [6.3.1. Active operating mode](#).

1. Stop the tramline counter by pressing the STOP TRAMLINE COUNTER button (1).

6.3.4. Setting the fertiliser target rate

- Adjusting of fertiliser target rate is optional.



Figure. 6.3.4. - 82. Setting the fertiliser target rate

- The fertiliser target rate (1) is set on the SHFT screen.
1. Press the SET button (2).
 - The first number starts to flash.
 2. Change the value by pressing the up/down arrow buttons.
 3. Confirm the value by pressing right arrow button.
 4. Repeat steps 2-3 for other numbers.



Figure. 6.3.4. - 83. Confirming the fertiliser target rate

5. Confirm the fertiliser target rate by pressing the OK button (1).

6.3.5. Selecting the setting method for adjusting of fertiliser target rate



Figure. 6.3.5. - 84. Changing the fertiliser target rate adjustment step

1. Change the fertiliser target rate adjustment step (1) by pressing the arrow buttons.
 - Pressing the up arrow button will increase the fertiliser target rate by the set step (default 5%). Pressing the down arrow button will decrease the fertiliser target rate by the set step (default 5%). The change in rate is displayed as a percentage (2) on the screen.
- Instructions on setting the step are provided in section [4.2.4.1. User setup](#).

6.3.6. Area counter use




Figure. 6.3.6. - 85. Resetting area counters

- The area seeded (1), seeding time (2) and average work performed (3) are displayed on the screen. Use the up/down arrow buttons to select information on each field (Ha1, Ha2 and total machine quantity). The total quantity cannot be reset.
1. Reset the field by pressing the RESET button (4).



Figure. 6.3.6. - 86. Confirming the resetting of area counters

2. Confirm the reset by pressing the YES button (1).

6.4. Feed units

The feeders are equipped with a push roller. In seed drills with a gearbox, the basic set-up of feed quantities is done by altering the effective roller length with screw-type control wheels. Fine-tuning is done from the machine's transmission by adjusting the gearbox control lever.

In seed drills without a gearbox, the rough tuning of the feed rate is done by chain gears and fine-tuning by altering the effective roller length with screw-type control wheels.

The feeders are powered by the machine's left running gear via a chain. In the feeder, there is a shut-off plate between the feeder chamber and the hopper to completely shut off the feed of the feeder chamber. Shutting part of the feeder with a shut-off plate allows seeding with incomplete working width or, for example, increasing row spacing by seeding with only every second coulter.

6.5. Seeding quantities

The seeding tables containing basic values for seed setting adjustment are located under the seed drill's transmission cover. The seeding tables for different varieties are presented below.




Figure. 6.5. - 87. Seeding table for machines with standard equipment




Figure. 6.5. - 88. Seeding table - small seed hopper




Figure. 6.5. - 89. Seeding table - seed gearbox 1




Figure. 6.5. - 90. Seeding table - seed gearbox 2




Figure. 6.5. - 91. Seeding table - seed gearbox 3




Figure. 6.5. - 92. Seeding table - seed and fertiliser gearbox 1




Figure. 6.5. - 93. Seeding table - seed and fertiliser gearbox 2




Figure. 6.5. - 94. Seeding table - seed and fertiliser gearbox 3

6.6. Preparations preceding hopper filling

6.6.1. Preparations preceding hopper filling in a machine without a gearbox

1. Ensure that the stability of the tractor and seed drill combination has been calculated.

- Guidelines on calculating the stability are found in the attachment *Calculating the stability of the tractor - seed drill combination*.
- 2. Ensure that the hopper is empty, clean and dry.
 - If needed, clean the hopper in accordance with section [7.3.1. Cleaning the hoppers](#).
- 3. Check that the hopper divider is in the desired position.
 - If needed, adjust the divider in accordance with section [6.6.4. Adjusting the hopper divider](#).
- 4. Perform the rough adjustment of the feeding quantity by using the chain gears in accordance with section [6.6.6. Adjusting the feeding quantity with chain gears](#).
- 5. Perform the fine adjustment of the feeding quantity in accordance with section [6.6.5. Adjusting the width of the feeder roller](#).
- 6. Adjust the position of the bottom flap of the feeder units in accordance with section [6.6.8. Adjusting the bottom flap position](#).
- 7. Adjust the position of the shut-off plates of the feeder units in accordance with section [6.6.9. Adjusting the shut-off plate position](#).

6.6.2. Preparations preceding hopper filling in a machine with a gearbox on the seed side or a dual gearbox

1. Ensure that the stability of the tractor and seed drill combination has been calculated.
 - Guidelines on calculating stability are found in the attachment *Calculating the stability of the tractor - seed drill combination*.
2. Ensure that the hopper is empty, clean and dry.
 - If needed, clean the hopper in accordance with section [7.3.1. Cleaning the hoppers](#).
3. Check that the hopper partition is in the desired position.
 - If necessary, adjust the divider in accordance with section [6.6.4. Adjusting the hopper divider](#).
4. Perform a rough adjustment of the feeding quantity in accordance with section [6.6.5. Adjusting the width of the feeder roller](#).
5. Perform a fine adjustment of the feeding quantity in accordance with section [6.6.7. Adjusting the feeding quantity with the gearbox control lever](#).
6. Adjust the position of the bottom flap of the feeder units in accordance with section [6.6.8. Adjusting the bottom flap position](#).
7. Adjust the position of the shut-off plates of the feeder units in accordance with section [6.6.9. Adjusting the shut-off plate position](#).

6.6.3. Preparations preceding hopper filling in a machine with a small seed hopper

1. Ensure that the stability of the tractor and seed drill combination has been calculated.
 - Guidelines on calculating the stability are found in the attachment *Calculating the stability of the tractor and seed drill combination*.
2. Ensure that the small seed hopper is empty, clean and dry.
 - If needed, clean the small seed hopper in accordance with section [7.3.2. Cleaning the small seed hopper](#).

3. Adjust the feeding quantity in accordance with section 6.6.10. Adjusting the width of the small seed feeder roller.
4. Adjust the position of the bottom flap of the small seed hopper's feeder units in accordance with section 6.6.11. Adjusting the bottom flap position in the feeder units of the small seed hopper.
5. Adjust the shut-off plates of of the small seed hopper's feeder units in accordance with section 6.6.12. Adjusting the shut-off plate position in the feeder units of the small seed hopper.

6.6.4. Adjusting the hopper divider




Figure. 6.6.4. - 95. Adjusting the hopper divider



DANGER

Before adjusting the divider, ensure that the hoppers are empty.

1. Remove the two locking pins (10) of one side of the divider (11).
2. Push the divider to the appropriate position.
3. Reinsert the locking pins.
4. Adjust the other side.

Table. 6.6.4. - 14. Hopper volumes with different divider positions on the Cerex 300.

Cerex 300	Seed (L)	Fertiliser (L)	Total (L)
1.	1,100	2,400	3,500
2.	1,250	2,250	3,500
3.	1,350	2,150	3,500
4.	1,450	2,050	3,500

5.	1,600	1,900	3,500
6.	1,700	1,800	3,500
7.	1,850	1,650	3,500
8.	1,950	1,550	3,500
9.	2,150	1,350	3,500

Table. 6.6.4. - 15. Hopper volumes with different divider positions on the Cerex 400

Cerex 400	Seed (L)	Fertiliser (L)	Total (L)
1.	1,500	3,300	4,800
2.	1,700	3,100	4,800
3.	1,850	2,950	4,800
4.	2,050	2,750	4,800
5.	2,200	2,600	4,800
6.	2,350	2,450	4,800
7.	2,500	2,300	4,800
8.	2,650	2,150	4,800
9.	2,800	2,000	4,800

6.6.5. Adjusting the width of the feeder roller




Figure. 6.6.5. - 96. Adjusting the width of the feeder roller

1. Adjust the width of the feeder roller to the settings provided in the seeding table by using the screw-type control wheels on the right-hand side of the hopper.
 - The seeding tables are provided in section [6.5. Seeding quantities](#).
The control wheel (1) is for seeds and control wheel (2) is for fertiliser. If the machine is equipped with adjusting of fertiliser target rate, there is no fertiliser control wheel.
The seed quantity increases when the seed control wheel is turned clockwise. The fertiliser quantity increases when the fertiliser control wheel is turned clockwise.
The main scale of seeding quantity is on the control wheel lock (3) and the secondary scale is on the control wheel rim (4).




Figure. 6.6.5. - 97. Feeder roller

- Feed quantities increase when the roller (1) is inserted into the feeder and decrease when the roller is pulled out of the feeder.

6.6.6. Adjusting the feeding quantity with chain gears

- If the seed drill is not equipped with a gearbox, the rough adjustment of the feeding quantity is carried out with the chain gears and the fine adjustment by adjusting the width of the roller.




Figure. 6.6.6. - 98. Changing the chain gears and chain

1. Loosen the tensioning wheel (1).
2. Remove the cotter (2) from the chain gear (3). Detach the chain (4) and the chain gear (3).
3. Attach a new chain gear and chain.
 - When seeding grain, use a chain gear with a pitch of $z = 15$.
 - When seeding grass, use a chain gear with a pitch of $z = 29$.
4. Replace the cotter and tighten the tensioning wheel.

6.6.7. Adjusting the feeding quantity with the gearbox control lever




Figure. 6.6.7. - 99. Gearbox control levers

- If the seed drill is equipped with a gearbox, the rough adjustment of the feeding quantity is done by adjusting the roller width and the fine adjustment is done from the machine transmission by adjusting the gearbox control lever. Control lever (1) is for fertiliser and control lever (2) is for seed. The feeding quantity increases when the value of the adjustment scale increases and vice versa.

Adjust the width of the feeder roller in accordance with section [6.6.5. Adjusting the width of the feeder roller](#). When seeding grain and fertiliser, the rollers should be in position 10. When seeding small seeds, rollers should be in position 2.

6.6.8. Adjusting the bottom flap position




Figure. 6.6.8. - 100. Adjusting the bottom flap position

1. Change the position of the control lever (1) in the front of the seed drill on the notch scale based on the material to be seeded.




Figure. 6.6.8. - 101. Bottom flap positions

- When seeding small seeds, the bottom flap should be in position 0.
When seeding grain and fertiliser, the bottom flap should be in position 1.
When seeding large seeds, such as peas or bean, the bottom flap should be in position 3.
When seeding organic fertilisers, the bottom flap should be in position 3.
- 2. Change the position of the control lever in the rear of the seed drill accordingly.
 - The rear control lever is adjusted from the working platform.

6.6.9. Adjusting the shut-off plate position




Figure. 6.6.9. - 102. Adjusting the shut-off plate position

1. Adjust the position of the shut-off plates (1) of the feeders in the seed and fertiliser side in accordance with the material to be seeded.
 - When seeding turnip rape and oilseed, the shut-off plate must be closed three notches.
When seeding grass, the shut-off plate must be closed two notches.
When seeding grain, fertiliser and beans, the shut-off plate must be completely open.
All shut-off plates should be in the same position.

6.6.10. Adjusting the width of the small seed feeder roller




Figure. 6.6.10. - 103. Adjusting the width of the small seed feeder roller

1. Adjust the width of the feeder roller to the settings provided in the seeding table by using the screw-type control wheel on the right-hand side of the small seed hopper.
 - The seeding tables are provided in section [6.5. Seeding quantities](#).
The main scale of seeding quantity is on the control wheel lock (2) and the secondary scale on the control wheel rim (1).




Figure. 6.6.10. - 104. Feeder roller of the small seed hopper

- Fed quantities increase when the roller (1) is inserted into the feeder and decreases when the roller is pulled out of the feeder.

6.6.11. Adjusting the bottom flap position in the feeder units of the small seed hopper




Figure. 6.6.11. - 105. Adjusting the bottom flap position in the feeder units of the small seed hopper

1. Change the position of the control lever (1) on the notch scale.




Figure. 6.6.11. - 106. Bottom flap positions in the feeder units of the small seed hopper

- When seeding small seeds, the bottom flap should be in position 0.

6.6.12. Adjusting the shut-off plate position in the feeder units of the small seed hopper




Figure. 6.6.12. - 107. Adjusting the shut-off plate position in the feeder units of the small seed hopper

1. Adjust the position of the shut-off plates (1) by the material to be seeded.
 - When seeding meadow fescue and ryegrass, the shut-off plate must be closed two notches.
When seeding clover, the shut-off plate must be closed three notches.
All shut-off plates should be in the same position.

6.7. Filling the hoppers



DANGER

Falling hazard when working on the platform. Be careful when working on the platform. Accessing the platform steps is allowed only when the machine is lowered.




Figure. 6.7. - 108. Working platform stairs

1. Lower the machine to the working position in accordance with section 6.2. Rendering the machine to the working position and lower the working platform stairs (1).




Figure. 6.7. - 109. Hopper tarp

2. Detach the two loops (2) of the hopper tarp (1).
3. Pull the cord (3).
 - There is a spring inside the tarp that will roll it up. Never let the go of the tarp, but hold the end until the tarp is open.
4. Fill the hopper(s) with seeds and/or fertiliser.



DANGER
Never go under a lifted load.



DANGER
Make sure that nobody is on top of the seed drill or inside the hoppers when the hoppers are being filled.



DANGER
Avoid breathing seed dressing dust and fertiliser dust. The seed dressing causes a serious health risk.



DANGER
Read the material safety data sheet of the dressing agent and fertiliser and follow their warnings.

- It is recommended that the hoppers be filled from the side of the hoppers. We recommend that you open the bulk bags using a knife with a long handle or a pruning hook.
5. Close the tarp (1) and attach the two tarp loops (2).
 6. Fold the working platform stairs up.
 - When raised, the stairs will be at an approximately 40 degree angle to the working platform.

6.8. Product calibration

The seeding tables that contain the basic values for adjusting the seeding quantity are located under the transmission cover in the seed drill. The seeding tables are provided in section [6.5. Seeding quantities](#). However, there are great differences between various seeds, which is why the actual seeding quantity must always be checked with a calibration test. Seed treatment, such as seed dressing, has considerable impact on fluidity.

The calibration test should be performed whenever changes are made to the feeding rates. In particular, fertiliser quantities may vary a lot due to the moisture and fluidity of the fertiliser.

When driving on the road with hoppers full of fertiliser and seeds, the vibration may cause arching in the hoppers. In the autumn or after rain, the fertiliser may absorb humidity in the feeders, changing fertiliser fluidity. For this reason, it is good to monitor that fertiliser or seed flow evenly from all feeders when seeding begins. Performing a calibration test is in order and visually checking that the feed rate is even in all feeders.




Figure. 6.8. - 110. Pulley

- When running a calibration test on the machine, the machine must be raised from its working position so that the pulley (1) comes off of the tyres.

6.8.1. Fertiliser calibration test in a machine without a gearbox or with a gearbox on the seed side



DANGER

Shut off the tractor, remove the key from the ignition and engage the parking brake before running a calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves in accordance with section [3.4. Using the middle marker ball valves](#).

1. Raise the transmission cover.




Figure. 6.8.1. - 111. Fertiliser calibration test. On the left, a machine without a gearbox and on the right, a machine equipped with a gearbox on the seed side.

2. Align the calibration trays (5) with the fertiliser side feeder axle by turning the crank (1) to position 1B.
 - The crank position 1A is for the seed side and the centre position is for seeding.
3. Check that the calibration trays are at the feeders and their lock (6) is turned to the side.
4. Remove the cotter pin (4) on the seed side from the feeder axle chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.
5. Attach the calibration test crank (3) to the calibration test axle. Turn the crank until an even flow of fertiliser comes out of all feeders. Empty the calibration trays.
6. Rotate the axle counterclockwise by 1 round per second using the calibration test crank.
 - An area of 100 m² is obtained by turning the crank 22 rounds on the Cerex 300 and 16.5 rounds on the Cerex 400.
7. Pull out the calibration trays and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold.
If the weighing result does not match the desired quantity, adjust the length of the roller in accordance with section 6.6.5. Adjusting the width of the feeder roller.
8. Repeat the calibration test. Ensure the result is close enough to the target quantity.
9. Place the calibration trays in the machine. Ensure that the trays are in the correct order and that they are connected to each other correctly.
10. Insert the cotter pins.
11. Turn the crank to bring the calibration trays to the seeding position.
12. Put the transmission cover back in place.

6.8.2. Fertiliser calibration test in a machine with a dual gearbox



DANGER

Shut off the tractor, remove the key from the ignition and engage the parking brake before running a calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves in accordance with section 3.4. Using the middle marker ball valves.

1. Raise the transmission cover.




Figure. 6.8.2. - 112. Fertiliser calibration test in a machine with a dual gearbox

2. Align the calibration trays (5) with the fertiliser side feeder axle by turning the crank (1) to position 1B.
 - The crank position 1A is for the seed side and the centre position is for seeding.
3. Check that the calibration trays are at the feeders and their lock (6) is turned to the side.
4. Remove the cotter (4) of the seed side from the feeder axle chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.
5. Attach the calibration test crank (3) to the calibration test axle. Turn the crank until an even flow of fertiliser comes out of all feeders. Empty the calibration trays.
6. Rotate the axle counterclockwise by 1 round per second using the calibration test crank.
 - An area of 100 m² is obtained by turning the crank 22 rounds on the Cerex 300 and 16.5 rounds on the Cerex 400.
7. Pull out the calibration trays and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold. If the weighing result does not match the desired quantity, adjust the gearbox control lever (7). The feeding quantity increases when the value of the adjustment scale increases.
8. Repeat the calibration test. Ensure the result is close enough to the target quantity.
9. Insert the cotter pins.
10. Turn the crank to bring the calibration trays to the seeding position.
11. Put the transmission cover back in place.

6.8.3. Calibration test with adjusting of fertiliser target rate - basic model

- This section contains instructions on running calibration tests when using the adjusting of fertiliser target rate in Comfort control system. If the machine does not have a gearbox or has a gearbox for the seed side, the calibration test must be run according to these instructions.

DANGER



Engage the tractor handbrake before running the calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves according to the instructions in section 3.4. Using the middle marker ball valves.

- The linear actuator only moves when the feeder shaft is rotating to prevent the feeders from being damaged.

1. Raise the transmission cover.




Figure. 6.8.3. - 113. Calibration test with adjusting of fertiliser target rate. On the left, a machine without a gearbox and on the right, a machine equipped with a gearbox.

2. Align the calibration trays (4) with the fertiliser side feeder shaft by turning the crank to position 1B.
 - The crank position 1A is for the seed side and the centre position is for seeding.
3. Check that the calibration trays are aligned with the feeders and their lock (5) is turned to the side.
4. Remove the cotter pin (3) on the seed side from the feed shaft chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.



Figure. 6.8.3. - 114. Setup screen

5. On the Setup screen of the user interface, select Product Calibration (1).
 - Use the up/down arrow buttons to scroll through the menu. Open the screen by pressing the OK button (2).



Figure. 6.8.3. - 115. Fertiliser target rate

6. Change the fertiliser target rate (1) by pressing the SET button (2).



Figure. 6.8.3. - 116. Setting the fertiliser target rate

- The first number starts to flash.
7. Change the value by pressing the up/down arrow buttons.
 8. Confirm the value by pressing right arrow button.

- One of the numbers starts to flash.
9. Repeat steps 7-8 for the second and third number.
 10. Press OK (1).



Figure. 6.8.3. - 117. Accepting the fertiliser target rate

11. Press the OK button (1).




Figure. 6.8.3. - 118. Calibration test crank. On the left, a machine without a gearbox and on the right, a machine equipped with a gearbox.

12. Attach the calibration test crank (1) to the calibration test shaft. Turn the crank until the linear actuator has moved into position.
 - The crank is turned 22 times on the Cerex 300 and 16.5 times on the Cerex 400.



Figure. 6.8.3. - 119. Starting the calibration test - basic model

13. Press the OK button (1).
14. Start the calibration test. Turn the crank until an even flow of fertiliser comes out of all feeders. Empty the calibration trays.
 - An area of 100 m² is obtained by turning the crank 22 times on a Cerex 300 and 16.5 times on a Cerex 400.
15. Pull out the calibration trays and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold.



Figure. 6.8.3. - 120. Setting the weighing result

- The weighing result (1) is displayed on the screen. The first number flashes.
16. Change the value by pressing the up/down arrow buttons.
 17. Confirm the value by pressing right arrow button.
 - One of the numbers starts to flash.
 18. Repeat steps 16-17 for other numbers.
 19. Confirm the correction by pressing the OK button (2).



Figure. 6.8.3. - 121. Calibration test calibration values - basic model

- The old calibration value (1), new calibration value (2), difference between the old and new value (as a percentage) (3) and maximum feed rate (4) are displayed on the screen.

20. Press the OK button (5).

21. Insert the cotter pins.

22. Turn the crank to bring the calibration trays to the seeding position.

23. Put the transmission cover back in place.

6.8.4. Calibration test with adjusting of fertiliser target rate - machine with dual gearbox

- This section contains instructions on running calibration tests when using the adjusting of fertiliser target rate in Comfort control system. If the machine has a dual gearbox, a calibration test must be run according to these instructions.

DANGER



Engage the tractor handbrake before running the calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves according to the instructions in section [3.4. Using the middle marker ball valves](#).

1. Raise the transmission cover.




Figure. 6.8.4. - 122. Calibration test with adjusting of fertiliser target rate on a machine with a dual gearbox.

2. Align the calibration trays (4) with the fertiliser side feeder shaft by turning the crank to position 1B.
 - The crank position 1A is for the seed side and the centre position is for seeding.
3. Check that the calibration trays are aligned with the feeders and their lock (5) is turned to the side.
4. Remove the cotter pin (3) on the seed side from the feed shaft chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.



Figure. 6.8.4. - 123. Setup screen

5. On the Setup screen of the user interface, select Product Calibration (1).
 - Use the up/down arrow buttons to scroll through the menu. Open the screen by pressing the OK button (2).



Figure. 6.8.4. - 124. Fertiliser target rate

6. Change the fertiliser target rate (1) by pressing the SET button (2).



Figure. 6.8.4. - 125. Setting the fertiliser target rate

- The first number starts to flash.
7. Change the value by pressing the up/down arrow buttons.
8. Confirm the value by pressing right arrow button.
- One of the numbers starts to flash.
9. Repeat steps 7-8 for the second and third number.
10. Press OK (1).



Figure. 6.8.4. - 126. Accepting the fertiliser target rate

11. Press the OK button (1).




Figure. 6.8.4. - 127. Calibration test crank

12. Attach the calibration test crank (1) to the calibration test shaft. Turn the crank until an even flow of fertiliser comes out of all feeders. Empty the calibration trays.
- An area of 100 m² is obtained by turning the crank 22 times on a Cerex 300 and 16.5 times on a Cerex 400.
13. Pull out the calibration trays and weigh the quantities they now contain.
- The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold.



Figure. 6.8.4. - 128. Entering the weighing result

- The weighing result (1) is displayed on the screen. The first number flashes.
14. Change the value by pressing the up/down arrow buttons.
15. Confirm the value by pressing right arrow button.
- One of the numbers starts to flash.
16. Repeat steps 14-15 for other numbers.
17. Confirm the correction by pressing the OK button (2).



Figure. 6.8.4. - 129. Calibration test calibration values - machine with dual gearbox

- The old calibration value (1), new calibration value (2), difference between the old and new value (as a percentage) (3) and maximum feed rate (4) are displayed on the screen.

18. Press the OK button (5).
19. Insert the cotter pins.
20. Turn the crank to bring the calibration trays to the seeding position.
21. Put the transmission cover back in place.

6.8.5. Seed calibration test in a machine without a gearbox



DANGER

Shut off the tractor, remove the key from the ignition and engage the parking brake before running a calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves in accordance with section 3.4. Using the middle marker ball valves.

1. Raise the transmission cover.




Figure. 6.8.5. - 130. Seed calibration test in a machine without a gearbox.

2. Align the calibration trays (4) with the seed side feeder axle by turning the crank to position 1A.
 - The crank position 1B is for the fertiliser side and the centre position is for seeding.
3. Check that the calibration trays are at the feeders and their lock (5) is turned to the side.
4. Remove the fertiliser side cotter pin (6) from the feeder axle chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.
5. Attach the calibration test crank (3) to the calibration test axle. Turn the crank until an even flow of fertiliser or seed comes out of all feeders. Empty the calibration trays.
6. Rotate the axle counterclockwise by 1 round per second using the calibration test crank.
 - An area of 100 m² is obtained by turning the crank 22 rounds on the Cerex 300 and 16.5 rounds on the Cerex 400.
7. Pull out the calibration trays and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the seeding quantities for a hectare will be hundredfold.
If the weighing result does not match the desired quantity, adjust the length of the roller in accordance with section 6.6.5. Adjusting the width of the feeder roller.
8. Repeat the calibration test. Make sure that the result is sufficiently close to the target quantity.
9. Place the calibration trays in the machine. Ensure that the trays are in the correct order and that they are connected to each other correctly.
10. Insert the cotter pins.
11. Turn the crank to bring the calibration trays to the seeding position.
12. Put the transmission cover back in place.

6.8.6. Seed calibration test in a machine with a gearbox on the seed side or a dual gearbox



DANGER

Shut off the tractor, remove the key from the ignition and engage the parking brake before running a calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves in accordance with section 3.4. Using the middle marker ball valves.

1. Raise the transmission cover.




Figure. 6.8.6. - 131. Seed calibration test. On the left, a machine without a gearbox and on the right, a machine equipped with a dual gearbox.

2. Align the calibration trays (5) with the seed side feeder axle by turning the crank (1) to position 1A.
 - The crank position 1B is for the fertiliser side and the centre position is for seeding.
3. Check that the calibration trays are at the feeders and their lock (6) is turned to the side.
4. Remove the cotter (7) of the fertiliser side from the feeder axle chain gear. If the machine is equipped with a small seed hopper, remove the cotter pin (2) of the small seed hopper.
5. Attach the calibration test crank (4) to the calibration test axle. Turn the crank until an even low of fertiliser or seed comes out of all feeders. Empty the calibration trays.
6. Rotate the axle counterclockwise by 1 round per second using the calibration test crank.
 - An area of 100 m² is obtained by turning the crank 22 rounds on the Cerex 300 and 16.5 rounds on the Cerex 400.
7. Pull out the calibration trays and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold.
If the weighing result does not match the desired quantity, adjust the length of the roller with the gearbox control lever. The feeding quantity increases when the value of the adjustment scale increases.
8. Repeat the calibration test. Make sure that the result is sufficiently close to the target quantity.
9. Replace the calibration trays in the machine. Ensure that the trays are in the correct order and that they are connected to each other correctly.
10. Insert the cotter pins.
11. Turn the crank to bring the calibration trays to the seeding position.
12. Put the transmission cover back in place.

6.8.7. Calibration test of the small seed hopper



DANGER

Shut off the tractor, remove the key from the ignition and engage the parking brake before running a calibration test. If the machine is equipped with middle markers, close the middle marker shut-off valves in accordance with section 3.4. Using the middle marker ball valves.




Figure. 6.8.7. - 132. Feeder funnel assembly of the small seed hopper

1. Open the four locking pins (2) of the feeder funnel assembly.
2. Set the feeder funnel assembly in the calibration test position by folding the funnel assembly down and pushing it towards the hopper. Lock the feeder funnel assembly in place by using the locking pins and the lower hole (1).
3. Insert the 2 calibration trays (3, 4) into place on the rail under the small seed hopper.




Figure. 6.8.7. - 133. Calibration test of the small seed hopper. The top figure shows a machine without a gearbox, the middle figure shows a machine with a gearbox on the seed side and the bottom figure shows a machine with a dual gearbox.

4. Remove the cotters of the fertiliser (1) or seed (2) side from the feeder axle chain gear.
5. Attach the calibration test crank (3) to the calibration test axle and turn it until an even flow of fertiliser or seed comes out of all feeders. Empty the calibration trays of the small seed hopper.
6. Rotate the axle counterclockwise by 1 round per second using the calibration test crank.
 - An area of 100 m² is obtained by turning the crank 22 rounds on the Cerex 300 and 16.5 rounds on the Cerex 400.
7. Pull out the calibration trays of the small seed hopper and weigh the quantities they now contain.
 - The calibration test quantity obtained corresponds to the area of 100 m², so the quantities for a hectare will be hundredfold.
If the weighing result does not match the desired quantity, adjust the length of the roller in accordance with section 6.6.10. Adjusting the width of the small seed feeder roller.
8. Repeat the calibration test. Make sure that the result is sufficiently close to the target quantity.
9. Put the feeder funnel assembly and cotters back in place.
10. Attach the calibration trays.
11. Put the transmission cover back in place.

6.9. Adjusting the seeding depth of the coulter




Figure. 6.9. - 134. Seeding depths

- The seeding depth of the coulter is adjusted per each coulter by means of the covering wheel. The label (1) shows the seeding depths in millimetres.




Figure. 6.9. - 135. Adjusting the seeding depth of the coulter

1. Remove the cotter pin (1).
2. Insert the pin (2) in the hole at the desired seeding depth and replace the cotter pin.

6.10. Adjusting the coulter pressure




Figure. 6.10. - 136. Adjusting the coulter pressure

1. Adjust the coulter pressure by altering the length of the two hydraulic cylinders (4-7).

- There are 2 hydraulic cylinders on the Cerex 300 and 4 on the Cerex 400.
 The cylinder turns the tube (4) of the coulter mounting, which causes the four rubber bars (2) to compress, resulting in increased force.
 The coulter pressure adjustment range is 20-80 kg. On light soil, use smaller pressure and on hard soil, greater pressure. The pressure should be first set too high and then lowered down, if needed, rather than adjusting the pressure too low in the first place. The coulter pressure can be adjusted during the operation. For example, it can be decreased at the end of the field with deep soil and increased at the end with clay soil, to maintain the desired seeding depth.
 The coulter pressure scale (1) shows the position of the coulter pressure. In the scale of 1-4, 4 is the highest coulter pressure.

6.11. Adjusting the rear harrow




Figure. 6.11. - 137. Adjusting the rear harrow

1. Use the bolt (1) to adjust the height of the rear harrow.
 - The longer the visible portion of the bolt, the higher the position of the rear harrow.
2. Adjust the angle of the rear harrow by inserting the rear harrow pin (2) in the appropriate hole (3).
 - There are three holes to choose from.
When the pin is in the bottom hole, the rear harrow is in an upright position. This position enables the rear harrow to move the most soil.
When the pin is in the top hole, the angle of the rear harrow position is the widest. This position is used if there is a lot of mass on the ground. This position enables the rear harrow to penetrate the ground best.

6.12. Adjusting the front levelling board




Figure. 6.12. - 138. Adjusting the front levelling board

1. Adjust the height of the front levelling board by placing clips (1) along the axles of the two hydraulic cylinders of the front levelling board.

Table. 6.12. - 16. The thicknesses and quantities of front levelling board clips

Clip colour	Clip thickness	Quantity
Yellow	31.8 mm	1 pcs
Red	25.4 mm	2 pcs
Black	22.2 mm	2 pcs
Blue	19.2 mm	2 pcs

- The more and the thicker the clips attached to the axle of the cylinder, the higher the position of the front levelling board.

6.13. Controlling the seeding depth

1. Drive at the normal seeding speed (8–12 km/h) approximately 10 metres and stop.
2. Stop the tractor, switch off the power and engage the parking brake.
3. Walk to the area you just sowed in the field and sweep loose soil from the surface of the field.
4. Check the depth of the seeding furrow and that there are seeds and fertiliser in the furrow.
 - If needed, adjust the seeding depth in accordance with section [6.9. Adjusting the seeding depth of the coulter](#).

6.14. Securing the position of the middle markers

1. When you drive along the second sowing lane, stop.

2. Stop the tractor, switch off the power and engage the parking brake.
3. Check the distance between the outermost rows of the sowing lanes.
 - The distance between the outermost rows of the sowing lanes must be 150 mm on the Cerex 300 and 154 mm on the Cerex 400.
4. If the distance is incorrect, adjust the middle markers in accordance with section [5.3.7. Adjusting the middle markers](#).

6.15. Emptying the hoppers

6.15.1. Emptying the hoppers to the calibration tray

- If the hopper is almost empty, the seed or fertiliser is directed to the calibration tray through the feeders and the tray is emptied. Instructions on performing the calibration test are provided in chapter [6.8.7. Calibration test of the small seed hopper](#).

6.15.2. Emptying the hoppers through the coulters




Figure. 6.15.2. - 139. Bottom flap open

1. Open the bottom flap (1) of the seed or fertiliser side for the hopper to be emptied.




Figure. 6.15.2. - 140. Calibration test crank

2. Use the calibration test crank (1) to rotate the feeders.
 - Emptying can be enhanced with compressed air to blow all seeds and fertiliser out of the hoppers and feeders.

6.16. Emptying the small seed hopper

6.16.1. Emptying the small seed hopper to the calibration tray

- If the small seed hopper is almost empty, the seeds are directed to the calibration tray through the feeders and the tray is emptied. The calibration test of small seed hopper is provided in section [6.8.7. Calibration test of the small seed hopper](#).

6.16.2. Emptying the small seed hopper through pipes




Figure. 6.16.2. - 141. Bottom flap of the small seed hopper open

1. Open the small seed hopper bottom flap by turning the control lever (1) downward.




Figure. 6.16.2. - 142. Calibration test crank

2. Use the calibration test crank (1) to rotate the feeders.
 - Emptying can be enhanced with compressed air to blow all seeds and fertiliser out of the hoppers and feeders.

6.17. Disconnecting from the tractor



DANGER

Crushing hazard when connecting and disconnecting the seed drill. Safety distance 5 m. Be extremely careful if someone else is near the seed drill and tractor giving instructions on connecting and disconnecting.



DANGER

Ensure that the tractor is turned off and the key is removed from the ignition.

1. Open the machine lifting circuit ball valve in accordance with section 5.3.5. Using the machine lifting circuit ball valve.
2. Disconnect the electric connections of the seed drill.
3. Disconnect the hydraulic hoses of the seed drill from the tractor.



DANGER

Depressurise the hydraulic system before disconnecting it. Follow the tractor manufacturer's instructions.



DANGER

Wear protective gloves when disconnecting the hydraulics.

4. Disconnect the drawbar of the seed drill from the tractor's hitch or disconnect the wheel packer from the tractor's link arms.

6.18. Machine storage

1. Clean the machine in accordance with section 7.3. Cleaning.
2. Lubricate all lubrication points in accordance with section 7.2. Lubrication.
 - Damaged paint can be touched up after washing. The painted surface can be protected with a light application of oil, using protective oil intended for the purpose.
3. For seasonal storage of the machine, use a dry place protected from sunlight.




Figure. 6.18. - 143. Cylinder stoppers

4. Place the 4 stoppers (4) on the lifting cylinder rod so that the coulters are slightly raised off the ground.
 - The Cerex 300 has 1 lifting cylinder (2), onto which the stoppers are placed. The Cerex 400 has 3 lifting cylinders (1 -3). The stoppers are placed on the outermost cylinders (1, 3).
5. Ensure that the value of coulters pressure adjustment is 1.
 - Instructions on the adjustment of coulters pressure are provided in section [6.10. Adjusting the coulters pressure](#).
6. Use wheel wedges or blocks to prevent the machine from moving during long-term storage.

7. Maintenance



DANGER

Depressurise the hydraulic system, disconnect the hoses and tractor's electrical connections and let the machine cool off before servicing.



DANGER

Crushing and cutting hazard in the machine's transmission when performing servicing and maintenance. Shut off the tractor, remove the key from the ignition and engage the parking brake before servicing.




Figure. 7. - 144. Cylinder stoppers



DANGER

Crushing hazard when performing servicing and maintenance. Place the 4 stoppers (4) on the lifting cylinder rod. The Cerex 300 has 1 lifting cylinder (2), onto which the stoppers are placed. The Cerex 400 has 3 lifting cylinders (1-3). The stoppers are placed on the outermost cylinders (1, 3). Place a stand or other support under the machine. Never go under the machine that is not propped up.



DANGER

Close the machine lifting circuit ball valve in accordance with section [5.3.5. Using the machine lifting circuit ball valve.](#)



DANGER

Crushing and cutting hazard in the machine transmission when performing servicing and maintenance. Before servicing, ensure that power is switched off in the tractor, the key is removed from the ignition and the parking brake is engaged.



DANGER

If the machine is equipped with middle markers, ensure that they have settled into their transport position and their ball valves are closed in accordance with section [3.4. Using the middle marker ball valves.](#)

7.1. Inspections

7.1.1. Quick instructions, inspections

The inspections to be performed on the seed drill are shown in the table below. The inspections to be carried out once per operating season must be performed in the spring when the machine is commissioned after winter storage.

Table. 7.1.1. - 17. Inspections to be performed on the seed drill

	1) After the first 10 hectares	2) Every 50 hectares	3) Every 500 hectares or once per operating season
<u>7.1.2. Checking bolt tightness</u>	X		X
<u>7.1.3. Checking tyre pressure</u>		X	X
<u>7.1.4. Checking the bearing clearance of the wheel packer hubs</u>			X
<u>7.1.5. Checking the tightness of the transmission chains</u>	X		X
<u>7.1.6. Checking the tightness of the wheel drive chain</u>	X		X
<u>7.1.7. Inspecting the wheel drive clutch</u>			X
<u>7.1.8. Inspecting the wheel drive clearance</u>	X		X
<u>7.1.9. Checking the condition of hydraulics</u>			X
<u>7.1.10. Checking the condition of electric wires</u>			X
<u>7.1.11. Inspecting the towing eye</u>			X
<u>7.1.12. Checking the gearbox oil level</u>			X
<u>7.1.13. Inspecting the coulter discs</u>			X
<u>7.1.14. Checking the functioning of the adjusting of fertiliser target rate</u>			X

7.1.2. Checking bolt tightness

7.1.2.1. Checking the tightness of the wheel bolts of the transport wheels




Figure. 7.1.2.1. - 145. Wheel bolts of the transport wheels

1. Ensure that all 60 of the wheel bolts (M20x1.5) (1) on the transport wheels are tight.
 - There are 60 wheel bolts on the Cerex 300 and 78 on the Cerex 400.
Tighten the bolts, if needed. If the gap between the tyres is narrow, tighten the bolts from the next gap by using a ratchet and a handle.
The bolts have been factory-installed with a locking compound.

7.1.2.2. Checking the tightness of the bolts in the flange bearings of the transport wheels




Figure. 7.1.2.2. - 146. Flange bearing bolts of the transport wheel assembly

1. Check that all the 24 flange bearing bolts (M16) (1) of the transport wheel assembly are tight.
 - Each bearing has four bolts. There are six bearings.
Tighten the bolts, if needed. If the gap between the tyres is narrow, tighten the bolts from the next gap by using a ratchet and a handle.

7.1.2.3. Checking the tightness of the wheel bolts of the wheel packer




Figure. 7.1.2.3. - 147. Wheel packer bar

1. Detach the two cotters (2) of the wheel packer bar (1).
2. Detach the wheel packer bar by lifting it.




Figure. 7.1.2.3. - 148. Wheel bolts of the wheel packer

3. Check that all the 20 wheel bolts (M18) (1) of the wheel packer are tight.
 - Tighten the bolts, if needed.
4. Replace the wheel packer bar and lock the bar with cotters.

7.1.2.4. Checking the tightness of coultter bolts




Figure. 7.1.2.4. - 149. Coultter shank bolts

1. Check that coultter shank bolts (M20) (1) are tight.
 - There are 12 coultter shank bolts on the Cerex 300 and 18 on the Cerex 400. If needed, tighten the bolts to torque 300 Nm.




Figure. 7.1.2.4. - 150. Coulters pressure bolts

2. Check that the coulters pressure U-bolt (1) nuts (2) are tight.
 - There are 4 U-bolts and 8 nuts on the Cerex 300. There are 8 U-bolts and 16 nuts on the Cerex 400.If needed, tighten the nuts to torque 100 Nm.




Figure. 7.1.2.4. - 151. Bolts of the coulters covering wheel and depth adjustment

3. Check that all the coulters covering wheel bolts (M16) (3, 4) are tight.
 - There are 40 coulters covering wheel bolts on the Cerex 300 and 52 on the Cerex 400.Tighten the bolts, if needed.
4. Check that the coulters depth adjustment bolts (M12) (1, 2) are tight.

- There are 40 coulters depth adjustment bolts on the Cerex 300 and 52 on the Cerex 400.
Tighten the bolts, if needed.

7.1.2.5. Checking the tightness of the working platform bolts




Figure. 7.1.2.5. - 152. Working platform bolts

1. Check that the 6 bolts (M12) (2) of the working platform are tight.
 - Tighten the bolts, if needed.
2. Check that the 4 bolts (M16) (1) near the lifting cylinder are tight.
 - Tighten the bolts, if needed.




Figure. 7.1.2.5. - 153. Working platform U-bolts

3. Check that the 8 nuts (M8) (2) of the U-bolts (1) are tight.
 - Tighten the nuts, if needed.

7.1.2.6. Checking the tightness of the towing eye bolts




Figure. 7.1.2.6. - 154. Towing eye bolts

1. Check that the 12 bolts (1) of the towing eye are tight.
 - If needed, tighten the bolts to torque 400 Nm.

7.1.3. Checking tyre pressure

- The correct rear tyre (250/80-18) pressure is 1.5 bar.
The correct tyre pressure of the wheel packer, available as an accessory, is 3.0 bar.

7.1.4. Checking the bearing clearance of the wheel packer hubs




Figure. 7.1.4. - 155. Checking the bearing clearance of the wheel packer hubs

1. Insert a bar (1) between the wheel and the platform.
2. Move the bar to ensure that there is no looseness in the wheel bearing.
 - If there is looseness in the wheel hub bearing, tighten the bearing in accordance with section [7.6.1. Tightening the bearing](#).

7.1.5. Checking the tightness of the transmission chains

7.1.5.1. Inspecting the tightness of the chains in a machine without a gearbox

1. Raise the transmission cover.




Figure. 7.1.5.1. - 156. Checking the tightness of the chains in a machine without a gearbox

2. Check the deflection of the fertiliser side chain (1) and the seed side chain (2) by pressing the chain down and lifting it up with your finger.
 - The maximum allowed chain deflection (A) is 10 mm. If needed, tighten the chains in accordance with section [7.5.1. Tightening the chains in a machine without a gearbox](#).
3. Put the transmission cover back in place.

7.1.5.2. Checking the tightness of chains in a machine with a gearbox on the seed side

1. Raise the transmission cover.




Figure. 7.1.5.2. - 157. Checking the tightness of the transmission chains in a machine with a gearbox on the seed side

2. Check the deflection of the fertiliser side chain (1) and the seed side chain (2) by pressing the chain down and lifting it up with your finger.
 - The maximum allowed deflection (A) is 10 mm. If needed, tighten the chains in accordance with section 7.5.2. Tightening the chains in a machine with a gearbox on the seed side.
3. Put the transmission cover back in place.

7.1.5.3. Checking the tightness of chains in a machine with a dual gearbox

1. Raise the transmission cover.




Figure. 7.1.5.3. - 158. Checking the tightness of the transmission chains in a machine with a dual gearbox

2. Check the deflection of the gearbox chain (2), fertiliser side chain (3) and seed side chain (1) by pressing the chain down and lifting it up with your finger.
 - The maximum allowed deflection (A) is 10 mm. If needed, tighten the chains in accordance with section 7.5.3. Tightening the chains in a machine with a dual gearbox.
3. Put the transmission cover back in place.

7.1.5.4. Checking the tightness of the chains in the small seed hopper transmission

1. Raise the transmission cover.




Figure. 7.1.5.4. - 159. Checking the tightness of the chains in the small seed hopper transmission

2. Check the deflection of the chains (1-3) by pressing the chain down and lifting it up with your finger.
 - The maximum allowed deflection (A) is 10 mm. If needed, tighten the chains in accordance with section 7.5.4. Tightening the transmission chains of the small seed hopper.
3. Put the transmission cover back in place.

7.1.6. Checking the tightness of the wheel drive chain




Figure. 7.1.6. - 160. Cover of the wheel drive housing

1. Open and remove the fastening bolts (1, 3) of the wheel drive housing and the housing cover (2).




Figure. 7.1.6. - 161. Wheel drive chain

2. Check the chain (1) deflection.
 - The maximum allowed chain deflection (A) is 10 mm. If needed, adjust the chain tension in accordance with section [7.7.1. Tightening the wheel drive chain](#).
3. Reattach the housing cover and fasten the two bolts of the cover.
 - Always use new locknuts to install.

7.1.7. Inspecting the wheel drive clutch

- The clutch should be inspected once per year / seeding season.




Figure. 7.1.7. - 162. Inspecting the clutch

1. Check the clearance of the flexible coupling element of the clutch (1).
 - Check the clearance of the flexible coupling element by measuring the distance between the hub and the flexible coupling element (2) by using a clearance gauge.
If the clearance is 3 mm or more, replace the flexible coupling element in accordance with section [7.7.2. Replacing the wheel drive clutch](#).

7.1.8. Inspecting the wheel drive clearance

1. Lower the machine to its working position.




Figure. 7.1.8. - 163. Inspecting the wheel drive clearance

2. Check the wheel drive clearance (A).
 - Measure the clearance between the wheel drive head and lower surface of the transport wheel. The clearance should be 3-5 mm.
To adjust the clearance, first loosen the locknut (1).
If the clearance is less than 3 mm, raise the drive wheel by turning the bolt (2) clockwise.
If the clearance is more than 5 mm, lower the drive wheel by turning the bolt (2) counterclockwise.
After adjusting, tighten the locknut (1).

7.1.9. Checking the condition of hydraulics

1. Check the tightness of the hydraulic system.
2. If needed, tighten the connections.
3. Make sure that the hoses are intact and have no leaks.
 - If necessary, contact maintenance.

7.1.10. Checking the condition of electric wires

1. Ensure that the insulation of the wires is not worn and that the wires are visible.
2. Ensure that the insulation of the wires have not melted and have no signs of heating or burning.
 - If needed, repair by using tape as additional insulation.
If a wire or leads of the wire are cut, contact maintenance.

7.1.11. Inspecting the towing eye

1. Check that the towing eye is not too worn.




Figure. 7.1.11. - 164. Wear in the towing eye

- The maximum wear (A) is 2.5 mm. The maximum size for the opening is 52.5 mm.
2. Check that there are no fractures in the towing eye.
- If needed, replace the towing eye in accordance with the instruction [7.8.1. Replacing the towing eye](#).

7.1.12. Checking the gearbox oil level




Figure. 7.1.12. - 165. Gearbox oil level

1. Check the oil level of the gearbox(es).
 - The oil level should be at 40-45 mm from the bottom of the fill hole (1). If needed, add oil.
The oil must be changed at least every five years to remove condensed water from the gearbox.
The correct oil volume is 0.8 litres. Use ISO VG32 grade hydraulic oil.

7.1.13. Inspecting the coultter discs




Figure. 7.1.13. - 166. Coultter discs

1. Check that the movement of discs (1) in relation to one another is slightly restrained and no clearance is felt in the bearing when turning a disc from the rear edge.
 - If the discs move easily in relation to one another or the bearing clearance is excessive, adjust the pretension with a shim.
If a disc does not rotate, clean the discs, if necessary, in accordance with section [7.3.4. Cleaning the coultter discs](#). If the disc still does not rotate, replace the disc, if needed, in accordance with section [7.9.2. Replacing a coultter disc](#) or replace the bearing in accordance with section [7.9.3. Replacing a coultter bearing](#).
2. Measure the diameter of the disc.
 - The disc should be round, with a minimum diameter of 350 mm. If the diameter is less than 350 mm, replace the disc, if necessary, in accordance with section [7.9.2. Replacing a coultter disc](#).

7.1.14. Checking the functioning of the adjusting of fertiliser target rate




Figure. 7.1.14. - 167. Checking the functioning of the adjusting of fertiliser target rate. On the left, a machine without a gearbox or a machine equipped with a gearbox (basic model). On the right, a machine with a dual gearbox.

1. Enable adjusting of fertiliser target rate and ensure that the dial (2, 4) moves on the fertiliser feeding quantity scale (1, 3).
 - On the basic model, the adjustment only moves when the seed axles rotate. On the machine with dual gearbox, the adjustment moves even when the seed axles do not rotate.

7.2. Lubrication

- After the commissioning of the machine, all lubrication points should be lubricated after the first 10 hectares.

The disc coulters are equipped with self-lubricating bearings, which do not need to be lubricated.

When lubricating, make sure that the grease nipple is open. Lubricate the point until grease flows out of the joint. Usually, 1-2 squeezes of a grease gun is enough for the grease nipples. Wipe off excess grease.

Use lithium-based lubricating grease for lubrication. The chains are lubricated with high-quality motor oil.

The use of viscous, long-fibre grease and grease containing solid lubricant particles (molybdenum sulphide and graphite) is prohibited.

7.2.1. Quick instructions, lubrication

Table. 7.2.1. - 18. Lubrication points

	1) Every 50 hectares	2) Every 500 hectares or once per operating season	Number of lubricating nipples in the machine (pcs)
<u>7.2.2. Lubricating the transmission chains</u>		X	
<u>7.2.3.1. Lubricating the wheel drive chain</u>		X	
<u>7.2.3.2. Lubricating wheel axle bearings</u>		X	3
<u>7.2.4. Lubricating the coulter pressure cylinder</u>		X	Cerex 300: 2 Cerex 400: 4
<u>7.2.5. Lubricating the rear axle mounting</u>		X	2
<u>7.2.6. Lubricating the wheel axle bearings</u>		X	6
<u>7.2.7. Lubricating the lifting cylinder</u>		X	Cerex 300: 2 Cerex 400: 6
<u>7.2.8. Lubricating the towing eye</u>		X	
<u>7.2.9. Lubricating the middle marker cylinders</u>		X	4
<u>7.2.10. Lubricating the rear marker cylinders</u>		X	4
<u>7.2.11. Lubricating the wheel packer pins and wheel hubs.</u>	X	X	6 (in pins) 4 (in wheels)
<u>7.2.12. Lubricating the front levelling board cylinders</u>		X	2
<u>7.2.13. Lubricating the drawbar cylinder</u>		X	2
<u>7.2.14. Lubricating the turnbuckle</u>		X	4

7.2.2. Lubricating the transmission chains

7.2.2.1. Lubricating the chains in a machine without a gearbox

1. Raise the transmission cover.




Figure. 7.2.2.1. - 168. Lubricating the chains in a machine without a gearbox

2. Lubricate the seed side chain (1) and the fertiliser side chain (2).
 - Make sure that oil also flows between the chain discs and not only in the reel.
3. Put the transmission cover back in place.

7.2.2.2. Lubricating the chains in a machine with a gearbox on the seed side

1. Raise the transmission cover.




Figure. 7.2.2.2. - 169. Lubricating the chains in a machine with a gearbox on the seed side

2. Lubricate the fertiliser side chain (1) and the seed side chain (2).
 - Make sure that oil also flows between the chain discs and not only in the reel.
3. Put the transmission cover back in place.

7.2.2.3. Lubricating the chains in a machine with a dual gearbox

1. Raise the transmission cover.




Figure. 7.2.2.3. - 170. Lubricating the chains in a machine with a dual gearbox

2. Lubricate the gearbox chain (2), fertiliser side chain (1) and the seed side chain (3).
 - Make sure that oil also flows between the chain discs and not only in the reel.
3. Put the transmission cover back in place.

7.2.2.4. Lubricating the small seed hopper transmission chains

1. Raise the transmission cover.




Figure. 7.2.2.4. - 171. Lubricating the small seed hopper transmission chains

2. Lubricate the chains (1-3).
 - Make sure that oil also flows between the chain discs and not only in the reel.
3. Put the transmission cover back in place.

7.2.3. Lubricating the wheel drive

7.2.3.1. Lubricating the wheel drive chain




Figure. 7.2.3.1. - 172. Wheel drive chain

1. Open and remove the two fastening bolts (1,3) of the wheel drive housing and the housing cover (2).
2. Lubricate the chain (14).
 - Make sure that oil also flows between the chain discs and not only in the reel.
3. Reattach the housing cover and fasten the two fastening bolts of the cover.
 - Always use new locknuts to fasten.

7.2.3.2. Lubricating wheel axle bearings




Figure. 7.2.3.2. - 173. Cover of the wheel drive housing

1. Open and remove the two fastening bolts (1, 3) of the wheel drive housing and the housing cover (2).




Figure. 7.2.3.2. - 174. Lubricating wheel axle bearings

2. Lubricate the 2 wheel drive bearings (2, 3) and the bearing (1) of the wheel drive support through the grease nipple.
 - Wipe away an old grease extruding from the bearing.
3. Reattach the housing cover and fasten the two fastening bolts of the cover.
 - Use new locknuts to fasten.

7.2.4. Lubricating the coulter pressure cylinder




Figure. 7.2.4. - 175. Lubricating the coulter pressure cylinder

1. Lubricate the coulter pressure cylinders (1).
 - There is 1 grease nipple at the top of the coulter pressure cylinder.
There are 2 coulter pressure cylinders on the Cerex 300 and 4 on the Cerex 400.

7.2.5. Lubricating the rear axle mounting




Figure. 7.2.5. - 176. Rear axle mounting

1. Lubricate the two link bushings of the rear axle mounting (1).
 - The link bushings are located in the rear corners of the hopper on both sides of the seed drill.

7.2.6. Lubricating the wheel axle bearings




Figure. 7.2.6. - 177. Wheel axle bearings

1. Lubricate the six wheel axle bearings (1).

7.2.7. Lubricating the lifting cylinder




Figure. 7.2.7. - 178. Lifting cylinder

1. Lubricate the lifting cylinder(s).

- There is 1 lifting cylinder (2) on the Cerex 300 and 3 lifting cylinders (1-3) on the Cerex 400.

There is a grease nipple at the top and bottom of the lifting cylinder.

7.2.8. Lubricating the towing eye




Figure. 7.2.8. - 179. Towing eye

1. Clean the towing eye (1) by wiping it.
2. Apply lubricant on the towing eye.

7.2.9. Lubricating the middle marker cylinders




Figure. 7.2.9. - 180. Middle marker cylinders

1. Lubricate the 2 middle marker cylinders (1).

- There is a grease nipple at the top and bottom of the middle marker cylinder.

7.2.10. Lubricating the rear marker cylinders




Figure. 7.2.10. - 181. Rear marker cylinders

1. Lubricate the 2 marker cylinders (1).

- There is 1 grease nipple (2) on the piston rod eye of both cylinders.

7.2.11. Lubricating the wheel packer pins and wheel hubs.




Figure. 7.2.11. - 182. Wheel packer pins

1. Lubricate the horizontal and vertical pin of the wheel packer.
 - The horizontal pin has two lubrication nipples (2,4). The vertical pin has two lubrication nipples (1,3).
2. Lubricate the two pins of the wheel packer bar.
 - There is one lubricating nipple (5) in both pins of the wheel packer bar.




Figure. 7.2.11. - 183. Detaching the wheel packer bar

3. Detach the two cotters (2) of the wheel packer bar (1).

4. Detach the wheel packer bar by lifting it.




Figure. 7.2.11. - 184. Wheel hubs of the wheel packer

5. Lubricate the four wheel hubs (1).
 - There is one lubricating nipple in the wheel hubs.
6. Replace the wheel packer bar and lock the bar with cotters.

7.2.12. Lubricating the front levelling board cylinders




Figure. 7.2.12. - 185. Front levelling board cylinders

1. Lubricate the 2 front levelling board cylinders (1).
 - There is one grease nipple at the top of both cylinders.

7.2.13. Lubricating the drawbar cylinder




Figure. 7.2.13. - 186. Drawbar cylinder

1. Lubricate the drawbar cylinder (1).
 - There is a grease nipple at the top and bottom of the drawbar cylinder.

7.2.14. Lubricating the turnbuckle




Figure. 7.2.14. - 187. Turnbuckle

1. Lubricate the turnbuckle (5).
 - The turnbuckle has 4 lubrication nipples (1-4).

7.3. Cleaning

7.3.1. Cleaning the hoppers

- Wear protective goggles and protective gloves when cleaning the hoppers. Clean the seed hopper when the variety to be seeded changes and at the end of the seeding season. Clean the fertiliser hopper at the end of the seeding season.




Figure. 7.3.1. - 188. Bottom flap

1. Open the bottom flap of the fertiliser side feed units in the front of the seed drill by turning the control lever (1) downward.
2. Open the bottom flap of the seed side feeder units in the back of the seed drill in the same way.
 - The back bottom flap should be opened from the working platform.




Figure. 7.3.1. - 189. Cleaning the hoppers

3. Remove the sieves (1, 2) of the fertiliser hopper (3).
4. Clean the fertiliser hopper with pressurised air.
5. Wash the fertiliser and seed hoppers (3, 4) with a detergent and warm water.

6. If needed, clean the hoppers with power wash.



CAUTION

Do not allow water to enter electrical instruments.

7. Dry the hoppers with pressurised air.
8. Close the bottom flaps of the feeder units.

7.3.2. Cleaning the small seed hopper

- Wear protective goggles and protective gloves when cleaning the hoppers.
Clean the small seed hopper when the variety to be seeded changes and at the end of the seeding season.




Figure. 7.3.2. - 190. Bottom flap open

1. Open the bottom flap of the feeder unit by turning the control lever (1) downward.




Figure. 7.3.2. - 191. Cleaning the small seed hopper

2. Clean the small seed hopper (1) with pressurised air.
3. Wash the small seed hopper with detergent and warm water.
4. If needed, clean the hopper with a pressure washer.



CAUTION

Do not allow water to enter electrical instruments.

5. Dry the hopper with pressurised air.
6. Close the bottom flap of the feeder unit.

7.3.3. Cleaning the paint surface

- Wear protective goggles and protective gloves when cleaning the paint surface.
Clean the paint surface at the end of the seeding season.

1. Clean the seed drill's paint surface by brushing and using pressurised air.
2. If needed, clean the paint surface with pressure washer.



CAUTION

Do not allow water to enter electrical instruments.

3. Lubricate all lubrication points in accordance with section 7.2. Lubrication.

- Damaged paint can be touched up after washing. The painted surface can be protected with a light application of oil, using protective oil intended for the purpose. Entry of protective oil on rubber and plastic parts should be avoided.

7.3.4. Cleaning the coulter discs

- Wear protective goggles and protective gloves when cleaning the discs of the coulters.




Figure. 7.3.4. - 192. Coulter discs

1. Clean the discs (1) of the coulters with a pressure washer.
 - Clean the clearance between the scraper and covering wheel as well.
2. Apply protective oil on wear parts to protect them from corrosion.
3. Once the discs are dry, turn each pair of coulter discs a few turns so that the scrapers remove the dry dirt from the inside of the discs.

7.3.5. Cleaning the feeder units

- Wear protective goggles and protective gloves when cleaning the feeder. Clean the feeder units at the end of the seeding season.




Figure. 7.3.5. - 193. Feeder roller

1. If there is seed or fertiliser residue left in the feeder roller (1), adjust the roller width in accordance with section 6.6.5. Adjusting the width of the feeder roller.
2. If there is still seed or fertiliser residue left in the feeder roller after the adjustment, clean the roller grooves with a wooden stick.

7.3.6. Cleaning the small seed hopper feeder units

- Wear protective goggles and protective gloves when cleaning the feeder . Clean the feeder units at the end of the seeding season.




Figure. 7.3.6. - 194. Feeder roller

1. If there is seed or fertiliser residue left in the feeder roller (1), adjust the roller length from side to side in accordance with section .
2. If there is still seed residue left in the feeder roller after the adjustment, clean the roller grooves with a wooden stick.

7.4. Transport wheel assembly wheel set

- This chapter describes the demounting and mounting of the wheel set. If you are unsure about how to perform the work, contact maintenance.

7.4.1. Demounting the wheel set



DANGER

Crushing and cutting hazard when removing the wheels.



DANGER

Ensure that the seed drill is set securely in place and that the lifting cylinder is in the transport position. Ensure that the seed drill cannot move in any direction.



DANGER

The wheel set demounting should be carried out by two people.




Figure. 7.4.1. - 195. Demounting the scraper

1. If the machine is equipped with a scraper, demount it by removing the bolts (1), washers (2, 3) and nuts (4).




Figure. 7.4.1. - 196. Demounting of the rear marker cylinders

2. Demount the 2 rear marker cylinders (4) by removing the cotter pins (1, 7), pins (2, 6) and washers (3, 5). Then, place the cylinders on the working platform.




Figure. 7.4.1. - 197. Demounting the rear harrow

3. If the machine is equipped with a rear harrow, demount it by removing the bolts (2), washers (3, 4) and nuts (5) of the rear harrow axle and detaching the rear harrow chains (1) from the working platform.




Figure. 7.4.1. - 198. Lifting the rear harrow



DANGER

Use hoisting equipment when demounting the rear harrow. Tie a lifting sling (1) around the tube (2).




Figure. 7.4.1. - 199. Transport supports

4. Install the transport supports (2) on both sides of the seed drill with M20x50 bolts (1).




Figure. 7.4.1. - 200. Demounting the wheel set

5. Remove the four bolts (1) of the flange bearing of the damaged wheel set from both sides of the wheel set.




Figure. 7.4.1. - 201. Turning the bolts

6. If you are demounting the outermost wheel set, turn the bearing bolts between the middle and the outermost wheel set to prevent the middle wheel set from falling.
 - Ensure that the bolts do not penetrate the back of the plate (2, 3).
If you are demounting the left-hand side wheel set, turn the bolts (4) so that their direction is from right to left. If you are demounting the right-hand side wheel set, turn the bolts (1) so that their direction is from left to right.
7. Raise the wheel set slightly.




Figure. 7.4.1. - 202. The wheel set is supported by the bolts

- The intact wheel sets remain supported by the bolts (1).



DANGER

Exercise caution when the wheel set comes loose.

7.4.2. Disassembling a wheel set




Figure. 7.4.2. - 203. Detaching a flange bearing

1. Open the locking screw (1).
2. Remove the flange bearing (2) from the axle.
 - Use an extraction tool to detach the bearing. Do not use a hammer to try to detach the bearing.
If needed, replace the bearing.




Figure. 7.4.2. - 204. Unfastening the wheel bolts

3. Remove the tyre by unfastening the six wheel bolts (1).
 - If the middle tyre of the wheel set needs to be replaced, the outermost tyre should also be demounted. The tyre should be demounted from the side of the centre tyre bolts in the pack.

7.4.3. Mounting a wheel set

1. Clean the surfaces before installing a wheel set.
2. Clean the threads of bolts.




Figure. 7.4.3. - 205. Mounting a tyre

3. Mount the tyre by tightening the six wheel bolts (1).
 - The tightening torque is 350 Nm. Apply medium-hard locking compound.




Figure. 7.4.3. - 206. Fastening the bearing

4. Fasten the flange bearing (2) to the axle and tighten the fastening screw (1).
 - If needed, replace a damaged bearing.

7.4.4. Mounting the wheel set




Figure. 7.4.4. - 207. Mounting the wheel set

1. Fasten the four bolts (1) of the flange bearing of the wheel set on both sides of the wheel set.
 - The tightening torque is 230 Nm. Use new locknuts.
2. Remove the transport supports.
3. If necessary, mount the scraper in accordance with section [5.1.7. Mounting the scraper](#), the rear harrow in accordance with section [5.1.8. Mounting the rear harrow](#) and the rear marker cylinders in accordance with section [5.1.9. Mounting the rear markers on the rear harrow](#).
 - The wheel bolts do not need to be retightened when locking compound has been applied during installation and the bolts have been tightened to the correct torque.

7.5. Tightening the transmission chains

7.5.1. Tightening the chains in a machine without a gearbox

1. Raise the transmission cover.




Figure. 7.5.1. - 208. Tightening the chains in a machine without a gearbox

2. Loosen the fertiliser side chain (1) by loosening the nut of the chain gear (3).
3. Loosen the seed side chain (4) by loosening the tensioning wheel (2).
4. Tighten the seed side chain by pushing the tensioning wheel to the right.
5. Tighten the tensioning wheel.
6. Tighten the fertiliser side chain by pushing the chain gear (3) down.
7. Tighten the chain gear nut (3).
8. Check the chains for deflection.
 - The deflection should be less than 10 mm.
9. Put the transmission cover back in place.

7.5.2. Tightening the chains in a machine with a gearbox on the seed side

1. Raise the transmission cover.




Figure. 7.5.2. - 209. Tightening the chains in a machine with a gearbox on the seed side

2. Loosen the fertiliser side chain (1) by loosening the nut of the chain gear (4).

3. Loosen the seed side chain (3) by loosening the nut of the chain gear (2).
4. Tighten the seed side chain by pushing the chain gear (2) downward.
5. Tighten the chain gear nut (2).
6. Tighten the fertiliser side chain by pushing the chain gear (4) downward.
7. Tighten the chain gear nut (4).
8. Check the chains for deflection.
 - The deflection should be less than 10 mm.
9. Put the transmission cover back in place.

7.5.3. Tightening the chains in a machine with a dual gearbox

1. Raise the transmission cover.




Figure. 7.5.3. - 210. Tightening the chains in a machine with a dual gearbox

2. Loosen the gearbox chain (3) by loosening the nut of the chain gears (1, 5).
3. Loosen the fertiliser side chain (2) by loosening the nut of the chain gear (6).
4. Tighten the seed side chain (4) by pushing the chain gear (5) downward.
5. Tighten the chain gear nut (5).
6. Tighten the gearbox chain by pushing the chain gear (1) downward.
7. Tighten the chain gear nut (1).
8. Tighten the fertiliser side chain by pushing the chain gear (6) downward.
9. Tighten the chain gear nut (6).
10. Check the chains for deflection.
 - The deflection should be less than 10 mm.
11. Put the transmission cover back in place.

7.5.4. Tightening the transmission chains of the small seed hopper

1. Raise the transmission cover.




Figure. 7.5.4. - 211. Tightening the transmission chains of the small seed hopper

2. Loosen the chain (1) by loosening the three bolts of the bearing housing (2).
3. Loosen the chain (6) by loosening the three bolts of the casing (5).
4. Loosen the chain (4) by loosening the three bolts of the bearing housing (3).
5. Tighten the chain by moving the bearing downward. Tighten the 3 bolts (2) of the bearing housing.
6. Tighten the chain (6) by moving the casing vertically and the chain (4) by moving the casing horizontally.
7. Tighten the three casing bolts (5) and the three bearing housing bolts (3).
8. Check the chains for deflection.
 - The deflection should be less than 10 mm.
9. Put the transmission cover back in place.

7.6. Wheel hub bearing clearance of the wheel packer

7.6.1. Tightening the bearing

1. Raise the tyre of the wheel packer off the ground.




Figure. 7.6.1. - 212. Hub cap

2. Remove the hub cap (1) by turning it counterclockwise.




Figure. 7.6.1. - 213. Tightening the bearing of the wheel hub

3. Remove the locking pin (3) of the slotted nut (2) on the axle.
4. Tighten the nut by turning the wheel simultaneously until light resistance is felt in the bearing (1).
5. Loosen the nut until the locking pin fits into the next slot where the bearing is rotating freely.
6. Lock the pin in place.
7. Fill a third of the cup's volume with lubricant and reinstall the hub cap by turning it clockwise.
 - The tightening torque is 50 Nm.

7.7. Wheel drive

7.7.1. Tightening the wheel drive chain




Figure. 7.7.1. - 214. Opening the wheel drive housing

1. Open and remove the two fastening bolts (1,3) of the wheel drive housing and the housing cover (2).




Figure. 7.7.1. - 215. Tightening the wheel drive chain

2. Loosen the mounting nut (1) located at the end of the chain gear.
3. Tighten the wheel drive chain (2) by moving the gear towards the transmission axle.
4. Tighten the mounting nut (1) of the chain gear and check the chain deflection.
 - The maximum allowed chain deflection is 10 mm.
5. Reattach the housing cover and fasten the two nuts of the cover.
 - Use new locknuts to install.

7.7.2. Replacing the wheel drive clutch

7.7.2.1. Demounting the clutch




Figure. 7.7.2.1. - 216. Demounting the clutch rubber

1. Open the locking screw (2) in the clutch body.
2. Separate the components of the clutch (1) by pulling the clutch on the axle towards the wheel drive mechanism.
3. Detach the flexible coupling element (3) of the clutch.

7.7.2.2. Installing the clutch




Figure. 7.7.2.2. - 217. Installing the clutch

1. Replace the flexible coupling element (3) of the clutch.
2. Push the clutch on the axle so that the clutch (1) terminals are tightly against each other.
3. Lock the clutch in place by tightening the locking screw (2).

7.8. Towing eye

7.8.1. Replacing the towing eye

7.8.1.1. Detaching the towing eye




Figure. 7.8.1.1. - 218. Towing eye

1. Remove the 12 bolts (1) of the towing eye.
2. Remove the towing eye (2).

7.8.1.2. Installing the towing eye




Figure. 7.8.1.2. - 219. Towing eye

1. Replace the towing eye (2).
2. Tighten the 12 bolts (1).
 - The tightening torque is 400 Nm.

7.9. Coulters



DANGER

Wear protective gloves during the servicing of the coulters.

- Wash the coulters before servicing.

7.9.1. Replacing a coulter

7.9.1.1. Demounting a coulter




Figure. 7.9.1.1. - 220. Disconnecting coulter hoses

1. Open the hose clamps (1,4) of the hoses (2, 3) at the end of the coulter and pull the hoses off of the coulter.




Figure. 7.9.1.1. - 221. Demounting a coulter

2. Lower the coulters to the ground and support the coulter to be demounted (1) to its place.



DANGER

The coulter weighs more than 40 kg and has sharp edges.

3. Loosen the four fastening bolts (4) of the coulter.
 - Do not remove the bolt right away but loosen all four bolts equally.
4. Remove the bolts, installation plate (2) and the four dampening rubbers (3).
5. Move the coulter from its location.

7.9.1.2. Installing a coulter

1. Move the coulter to its location.



DANGER

Use a lifting aid to move the coulter. The coulter weighs more than 40 kg and has sharp edges.




Figure. 7.9.1.2. - 222. Fastening the coulter

2. Set the lowest rubber damper (3) in its place and lift the coulter (1) against the mounting beam.
3. Install the remaining 3 rubber dampers (5).
4. Replace the washer (2).
5. Install the 4 fastening bolts and nuts (4) and tighten the bolts evenly to eliminate any gap between the mounting plates.
 - Use new locknuts with a strength rating of 10 to fasten.




Figure. 7.9.1.2. - 223. Connecting coulter hoses

6. Connect the hoses (2, 3) in the appropriate locations in the coulter.
 - The front hose (2) comes from the fertiliser hopper and the rear hose (3) comes from the seed hopper.
7. Tighten the hose clamps (1,4).

7.9.2. Replacing a coulter disc

7.9.2.1. Detaching a disc

- If necessary, demount the coulter as defined in section [7.9.1.1. Demounting a coulter.](#)




Figure. 7.9.2.1. - 224. Detaching a disc

1. Remove the mounting bolts (2) (5 pcs) of the disc (1).

- The disc will fall off.
Replace the bearing when changing a disc.




Figure. 7.9.2.1. - 225. Detaching the bearing housing

2. Loosen the bearing bolt (2) and remove the bolt and the washer (1).

- The left-side disc has a left-hand thread and the right-side disc has a right-hand thread.
3. Remove the bearing housing (3).
 - Use a puller to remove the bearing housing.

7.9.2.2. Installing a disc

- Install the bearing in accordance with section [7.9.3.2. Installing a bearing](#).




Figure. 7.9.2.2. - 226. Installing the bearing housing

1. Clean the plane surface (3) of the bearing housing.
2. Mount the bearing housing onto the coulters axle.
3. Replace the M16 washer and fasten the M16 bolt (2).
 - The left-side disc has a left-hand thread and the right-side disc has a right-hand thread.




Figure. 7.9.2.2. - 227. Installing the disc

4. Mount the disc (1) onto the coultter axle.
5. Fasten the M12 x 1.5 bolts (2) (5 pcs) of the bearing cap.

7.9.3. Replacing a coultter bearing

7.9.3.1. Detaching a bearing

- Remove the coultter disc in accordance with section [7.9.2.1. Detaching a disc.](#)




Figure. 7.9.3.1. - 228. Bearing seal and shim

1. Detach the bearing seal (1) and shim (2) from the back of the bearing housing (3).




Figure. 7.9.3.1. - 229. Removing the bearing and O-ring

2. Detach the O-ring (3) from the front of the bearing.
3. Remove the bearing (2) from the bearing housing (1).
 - Detach the bearing from the back of the bearing housing using a clamp.

7.9.3.2. Installing a bearing




Figure. 7.9.3.2. - 230. Installing a bearing

1. Clean the bearing housing (1).
2. Install the new bearing (2).
 - Install the bearing using a clamp.
3. Replace the O-ring (3).




Figure. 7.9.3.2. - 231. Bearing seal and shim

4. Replace the shim (2) and bearing seal (1(3))

- The seal should be changed when the bearing is changed.

7.9.4. Replacing the coultter covering wheel

7.9.4.1. Demounting the covering wheel




Figure. 7.9.4.1. - 232. Demounting the covering wheel

1. Remove the locknut (1) of the covering wheel (2) and pull the covering wheel off of the coultter.

7.9.4.2. Installing the covering wheel




Figure. 7.9.4.2. - 233. Installing the covering wheel

1. Reattach the covering wheel (4) and fasten it with a bolt M16x100 (2), two washers M16 (1) and nut M16 (3).

- Use new locknuts when installing.

7.9.5. Adjusting the scrapers

7.9.5.1. Adjusting the disc scraper



DANGER

Use caution - the disc edges are sharp.




Figure. 7.9.5.1. - 234. Disc scraper

1. Loosen the bolt (1) of the scraper (2).
2. Adjust the distance between the scraper and the discs by moving the scraper up or down.
 - The scraper and inner plate under it must be kept together. Adjust the scraper and inner plate as close to the discs as possible but ensure that the disc does not make contact with the scraper or inner plate at any point. The disc must turn freely.
3. Tighten the scraper fastening bolt.

7.9.5.2. Adjusting the cover wheel scraper




Figure. 7.9.5.2. - 235. Cover wheel scraper

1. Loosen the two fastening nuts (1, 2) of the cover wheel scraper (3)
2. Adjust the distance between the scraper and the cover wheel by moving the scraper up or down.
 - The distance between the scraper and the cover wheel should be 2-3 mm.
3. Tighten the scraper fastening nuts.

7.10. Comfort control system maintenance

7.10.1. Manual calibration of the speed sensor

1. First, select User setup (2. User setup) on the user interface Setup screen and then Seed drill (6. Drill Setup).




Figure. 7.10.1. - 236. Calibration start screen in the user interface

2. Move the cursor to Speed sensor (SSF) (1) with the arrow buttons and press the OK button (2).
 - The first number starts to flash.
3. Change the value by pressing the up/down arrow buttons.
4. Confirm the value by pressing the right arrow button.
5. Repeat steps 3-4 for other numbers.
6. Confirm the correction by pressing the OK button (2).

7.10.2. Calibration of the speed sensor while driving

1. Select User setup and Seed drill on the user interface.




Figure. 7.10.2. - 237. Calibration start screen in the user interface

2. Move the cursor to Speed sensor (SSF Autocal) (1) and press the OK button (2).



Figure. 7.10.2. - 238. Driving the tractor - start

3. Press the OK button (1).
4. Drive the tractor 100 metres.



Figure. 7.10.2. - 239. Driving the - end

5. Press the OK button (2).
 - The new calibrated value (1) appears on the screen.
6. Accept by pressing OK button (2) or rerun the calibration by pressing ESC button (3).












Figure. 7.10.2. - 240. New calibrated value



- The new calibrated value (1) appears on the screen.

8. Fault situations

8.1. Troubleshooting the Comfort control system

Error	Display	Measures
Seed level in the hopper is too low.		Fill the seed hopper.
Fertiliser level in the hopper is too low.		Fill the fertiliser hopper.
The tramline seed clutch is not working and no pulses are coming from the seed shaft.		Check that the shaft rotates. Check the sensors.
The tramline fertiliser clutch is not working and no pulses are coming from the seed shaft.		Check that the shaft rotates. Check the sensors.
The tramline seed clutch is not working and pulses are coming from the seed shaft while making a tramline.		Check that the shaft does not rotate. Check the sensors.
The tramline fertiliser clutch is not working and pulses are coming from the seed shaft while making a tramline.		Check that the shaft does not rotate. Check the sensors.

<p>The middle marker automation or tramline counter is not working. The tramline counter is set to the STOP position.</p>		<p>Ensure that the checks shown in the figure are NOT on the arrows.</p>
<p>Basic model</p> <p>The linear actuator for adjusting of fertiliser target rate is at 0 and not moving. The fertiliser calibration has failed and is outside the T-value limits.</p>		<p>On the Setup screen, select 3. Factory Setup</p> <p>→ enter the PIN code 1234</p> <p>→ select 2. Actuator Setup</p> <p>→ select STR as your Line Type setting</p> <p>→ select Line Factors</p> <p>→ set the T-value manually.</p> <p>If only "#####" is shown on the line, go to the line by pressing OK. First enter "000000" as the value and then accept it by pressing the OK button. The value "0.00000" should now appear on the line.</p> <p>Repeat the above and enter "3.0000" as the value.</p>

<p>Machine with dual gearbox</p> <p>The linear actuator for the fertiliser remote control is at 0 and not moving. The fertiliser calibration has failed and is outside the T-value limits.</p>		<p>On the Settings screen, select 3. Factory Setup</p> <p>→ enter the PIN code 1234</p> <p>→ select 2. Actuator Setup</p> <p>→ select CUR as your Line Type setting</p> <p>→ select Curve Factors</p> <p>→ set the T-value manually.</p> <p>If only "#####" is shown on the line, go to the line by pressing OK. First enter "000000" as the value and then accept it by pressing the OK button. The value "0.00000" should now appear on the line.</p> <p>Repeat the above and enter "0.40000" as the value.</p>
<p>The middle markers do not work automatically or in the manual position.</p> <p>A new value has been entered for the fertiliser rate and the linear actuator has not reached the target.</p> <p>On basic models, the seed shaft has to rotate in order for the linear actuator to move.</p>		<p>Check the function adjusting of fertiliser target rate according to section 7.1.14. Checking the functioning of the adjusting of fertiliser target rate.</p>

8.2. Troubleshooting of the seed drill

Table. 8.2. - 19. Troubleshooting of the seed drill

Problem	Cause	Measures
The quantity of seed or fertiliser fed by the machine is higher than indicated by the calibration test.	1. The bottom flap position is incorrect	1. Check the position of the bottom flap in accordance with section 6.6.8. Adjusting the bottom flap position or section 6.6.11. Adjusting the bottom flap position in the feeder units of the small seed hopper .
	2. The calibration test table is indicative	2. Check the feeding quantity by means of the calibration test in accordance with section 6.8. Product calibration .
	3. Seed moves in a different manner at the beginning and after a few hectares	3. Run a calibration test again in accordance with section 6.8. Product calibration after a few hectares, particularly at the beginning of the season.
The quantity of seed or fertiliser fed by the machine is lower than indicated by the calibration test.	1. The bottom flap position is incorrect	1. Check the position of the bottom flap in accordance with section 6.6.8. Adjusting the bottom flap position or section 6.6.11. Adjusting the bottom flap position in the feeder units of the small seed hopper .
	2. The calibration test table is indicative	2. Check the feeding quantity by means of the calibration test in accordance with section 6.8. Product calibration .
	3. The seed or fertiliser bridging has occurred in the hopper.	3. Ensure that the fertiliser is not clumping and there is no excess material in the hopper.
	4. The feeder roller is obstructed.	4. Clean the feeder roller in accordance with section 7.3.5. Cleaning the feeder units or section 7.3.6. Cleaning the small seed hopper feeder units .
	5. The wheel drive operation is compromised	5. Check the wheel drive function in accordance with section 7.1.6. Checking the tightness of the wheel drive chain , section 7.1.7. Inspecting the wheel drive clutch and section 7.1.8. Inspecting the wheel drive clearance .

The machine cannot be lifted	1. The lift inhibit function is enabled	1. Disable the lift inhibit function in accordance with section <u>6.3.1. Active operating mode</u> .
	2. Machine lifting circuit ball valve is closed	2. Open the machine lifting circuit ball valve in accordance with section <u>5.3.5. Using the machine lifting circuit ball valve</u> .
	3. The quick coupling is open	3. Check the connection of the quick-release coupling.
The machine cannot be lowered	1. Machine lifting circuit ball valve is closed	1. Open the machine lifting circuit ball valve in accordance with section <u>5.3.5. Using the machine lifting circuit ball valve</u> .
	2. The quick coupling is open	2. Check the connection of the quick-release coupling.
	3. The stoppers are in place in the lifting cylinder	3. Remove the stoppers from the lifting cylinder.
Hopper alarm does not function	1. The alarm has been disabled	1. Enable the alarm from the settings in accordance with section <u>4.2.4.1. User setup</u> .
The axle rotation guard does not function	1. The alarm has been disabled	1. Enable the alarm from the settings in accordance with section <u>4.2.4.1. User setup</u> .

9. Attachments

1. EC Declaration of Conformity
2. Hydraulic schematics
3. Electrical schematics
4. Connection socket according to SFS 2473
5. Calculating the stability of the tractor - seed drill combination

EC DECLARATION OF CONFORMITY

DOMETAL OY

Kotimäentie 1
FI-32210 Loimaa
Finland

hereby states that the following seed drills in question

Multiva Cerex 300 starting from serial number 000-090403-L1010001

Multiva Cerex 400 starting from serial number 000-090404-L1010001

Multiva FORTE FX300 starting from serial number 000-090303-L1010001

Multiva FORTE FX400 starting from serial number 000-090304-L1010001

meet the requirements of Machinery Directive 2006/42/EC with respect to the construction of machinery.

Furthermore, the following standards were applied in the design of the machine:

SFS-EN 12100 (2010)

SFS-EN 14018 + A1 (2010)

SFS-EN ISO 4254-1 (2013)


Loimaa, 28 October 2019






Vesa Mäkelä
Kotimäentie 1
FI-32210 Loimaa
Finland

The undersigned is also authorised to compile technical documentation for the above machines.
Translation of the original file


Hydraulic schematics Cerex 300




Lifting and lowering the machine (LC)
with middle markers (CMR/CML) and rear markers (RMR/RML)




Hydraulic schematics Cerex 400




Lifting and lowering the machine (LC)
with middle markers (CMR/CML) and rear markers (RMR/RML)



Coulter pressure





Front levelling board



Drawbar cylinder

Electrical schematics






PCB INTERNAL WIRING				
CABLE ASSEMBLY	CORE COLOUR	PCB POSITION	FUNCTION	
POWER LEAD	BROWN	+V IN	+V	
	BLUE	0V IN	0V	
TRAMLINE O/P1 LOOM (TL1)	BLUE	PL2 - 2	TRAMLINE O/P1 +V	
	RED	PL2 - 3	TRAMLINE O/P1 COMMON	
	GREEN	PL3 - 18	TRAMLINE O/P1 0V	
	YELLOW	PL3 - 19	TRAMLINE O/P1 SIG	
TRAMLINE O/P2 LOOM (TL2)	BLUE	PL2 - 5	TRAMLINE O/P2 +V	
	RED	PL2 - 6	TRAMLINE O/P2 COMMON	
	GREEN	PL3 - 5	TRAMLINE O/P2 0V	
	YELLOW	PL3 - 6	TRAMLINE O/P2 SIG	
LEFT SOLENOID LEAD (L)	BROWN	PL2 - 8	LEFT SOLENOID +V	
	BLUE	PL2 - 9	LEFT SOLENOID COMMON	
RIGHT SOLENOID LEAD (R)	BROWN	PL2 - 11	RIGHT SOLENOID +V	
	BLUE	PL2 - 12	RIGHT SOLENOID COMMON	
TRAMLINE SENSOR LEAD (G)	BLUE	PL3 - 1	TRAMLINE SENSOR 0V	
	BLACK	PL3 - 2	TRAMLINE SENSOR SIG	
	BROWN	PL3 - 20	TRAMLINE SENSOR +V	
FORWARD SPEED LEAD (H)	BLUE	PL3 - 7	FORWARD SPEED 0V	
	BLACK	PL3 - 8	FORWARD SPEED SIG	
	BROWN	PL3 - 21	FORWARD SPEED +V	
SEED LEVEL SENSOR LEAD (N1)	BROWN	PL3 - 11	SEED LEVEL SENSOR +V	
	BLUE	PL3 - 12	SEED LEVEL SENSOR 0V	
	BLACK	PL3 - 13	SEED LEVEL SENSOR SIG	
FERT LEVEL SENSOR LEAD (N2)	BROWN	PL3 - 14	FERT LEVEL SENSOR +V	
	BLUE	PL3 - 15	FERT LEVEL SENSOR 0V	
	BLACK	PL3 - 16	FERT LEVEL SENSOR SIG	

If lift inhibit, move
PL2-5->PL2-2 and
PL2-6-> PL2-3
Lift inhibit coil will be
connect to PL2-5
and PL2-6

PCB LINK INFORMATION	
LK1	SOLDERED
LK2	JUMPER PRE-FITTED IN POSITION 'B'
LK3	JUMPER PRE-FITTED IN POSITION 'STD' FERTILISER REMOTE CONTROL 'PLUS'
LK4	JUMPER PRE-FITTED POSITIONED ON 2 PINS CLOSEST TO THE FUSE
LK5	TRACKED THROUGH (NO ACTION REQUIRED)

Connection socket according to SFS 2473

1/L	Left turn signal
2/54G	Free
3/31	Ground
4/R	Right turn signal
5/58R	Right rear light + lic. plate light
6/54	Brake light
7/58L	Left rear light

Calculating the stability of the tractor - seed drill combination

The load may impact the steerability of the tractor. The dead weight of the machine and the materials in the hoppers may result in the loss of the stability of the tractor - seed drill combination.

This Appendix provides a recommendation on how to ensure the stability of the tractor - seed drill combination by means of calculation.

The following formula can be used to calculate the tractor's minimum weight $I_{F,min}$, which will allow the load on the front axle to be 20% of the weight of an empty tractor:

$$I_{F,min} = \frac{(I_R \times (c+d)) - (T_F \times b) + (0,2 \times T_E \times b)}{a+b}, \text{ in which}$$

T_E	[kg]	Tractor's dead weight ¹⁾
T_F	[kg]	Front axle load of an empty tractor ¹⁾
T_R	[kg]	Rear axle load of an empty tractor ¹⁾
I_R	[kg]	Total weight of the implement or rear ballast installed in the rear ²⁾
I_F	[kg]	Total weight of the implement or front installed in the front ²⁾
a	[m]	Distance between the centre of mass of the implement or front ballast installed in the front and the centre of the front axle ^{2) 3)}
b	[m]	Tractor's wheelbase ¹⁾
c	[m]	Distance between the centre of the rear axle and the centre of the connecting point of the link arm ^{1) 3)}
d	[m]	Distance between the centre of the connecting point of the link arm and the centre of mass of the implement or rear ballast installed in the rear ²⁾

- 1) See the tractor manual
- 2) See the implement manual
- 3) To be measured




Figure 1. Calculating the stability of the tractor - seed drill combination